



**Broadcast Electronics**

4100 North 24<sup>th</sup> Street, Quincy, Illinois 62305 USA • Phone (217) 224-9600 • Fax (217) 224-9607 • [www.bdcast.com](http://www.bdcast.com) • [bdcast@bdcast.com](mailto:bdcast@bdcast.com)

---



## **STXe 500 Watt FM Exciter**

### **Technical Manual**

597-4063  
Revision F  
June 25, 2018



## **STXe 500 Watt FM Exciter**

### **Technical Manual**

©2018 Broadcast Electronics all rights reserved.

The information in this publication is subject to improvement and change without notice. Although every effort is made to ensure the accuracy of the information in this manual, Broadcast Electronics accepts no responsibility for any errors or omissions. Broadcast Electronics reserves the right to modify and improve the design and specifications of the equipment in this manual without notice. Any modifications shall not adversely affect performance of the equipment so modified.

### **Proprietary Notice**

This document contains proprietary data of Broadcast Electronics. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, translated into any other language in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose, without the express written permission of Broadcast Electronics.

### **Trademarks**

Broadcast Electronics and the BE logo are registered trademarks of Broadcast Electronics.

Marti Electronics and the Marti logo are registered trademarks of Broadcast Electronics.

All other trademarks are property of their respective owners.

### **Copyright**

Copyright laws protect artwork depicting circuitry in this manual.

Information in this manual is subject to change without notice and does not represent a commitment on the part of Broadcast Electronics.

Broadcast Electronics may make improvements and/or changes in this manual or in the product described herein at any time.

This product could include technical inaccuracies or typographical errors.



## Broadcast Electronics Product Warranty (Two-Year Limited)

Broadcast Electronics hereby warrants all new products manufactured by Broadcast Electronics against any defects in material or workmanship at the time of delivery thereof, or that develop under normal use within a period of two (2) years from the date of shipment.

Broadcast Electronics reserves the right to repair equipment under warranty with new or refurbished equipment or parts. Broadcast Electronics' sole responsibility, with respect to any equipment or parts not conforming to this warranty, is to replace or repair such equipment upon the return thereof F.O.B. to Broadcast Electronics' factory in Quincy, Illinois, U.S.A. In the event of replacement pursuant to the foregoing warranty, only the unexpired portion of the warranty from the time of the original purchase will remain in effect for any such replacement.

This warranty shall exclude the following products, component parts and/or assemblies:

- (a) Transmitter power output tubes shall only carry the original manufacturers' or suppliers' standard warranty in effect on their original shipment date.
- (b) All computers, computer peripherals, cables, hard disk drives, etc., shall only carry the manufacturers' or suppliers' standard warranty in effect on their original shipment date.
- (c) "Components", defined as separate and individual parts (e.g. transistors, integrated circuits, capacitors, resistors, inductors, fans, etc.), resold by Broadcast Electronics from another manufacturer or supplier, shall only carry a 90-day warranty, effective the date of shipment. Any such "Components" being returned for warranty claim must be (1) returned in their original packaging and (2) must be in new, unused condition. Broadcast Electronics is unable to process or resolve component defects or performance concerns on components that have been soldered, installed, wired or in any way altered from their new condition.
- (d) "Resale Equipment", defined as equipment purchased from another manufacturer or supplier, then resold by Broadcast Electronics, shall only carry such manufacturer's or suppliers' standard warranty in effect as of the original shipment date. All warranty claims against any and all "resale equipment" sold by Broadcast Electronics must be filed directly with the original equipment manufacturer. Broadcast Electronics is unable to process or resolve equipment defects or performance concerns on products or services not manufactured by Broadcast Electronics.

This warranty shall not extend to claims resulting from any acts of God, terrorism, war, defects or failures caused by Purchaser or user abuse or misuse, operator error, or unauthorized attempts to repair or alter the equipment in any way.

Under no circumstances shall Broadcast Electronics be responsible for indirect, incidental or consequential damages, including, but not limited to transportation costs, non-authorized repair or service costs, downtime costs, costs for substituting equipment or loss of anticipated profits or revenue incurred by Purchaser, whether based in contract, tort or for negligence or breach of statutory duty or otherwise. The terms of the foregoing warranty shall be null and void if the equipment has been altered or repaired without specific written authorization from Broadcast Electronics, or if not installed according to Broadcast Electronics' instruction manuals, including, but not limited to, the absence of proper grounding, surge (TVSS) protection on the AC circuit panel or proper lightning protection/grounding on all output circuits, or if equipment is operated under environmental conditions or circumstances other than those specifically described in Broadcast Electronics' product literature or instruction manual which accompany the equipment. **The warranty shall be voided if the product or subassembly is equipped with a tamper seal and that tamper seal is broken.** Broadcast Electronics shall not be liable for any expense of any nature whatsoever incurred



this warranty. If the equipment is described as “used” equipment, it is sold as is and where is and no warranty applies unless authorized in writing.

EXCEPT AS SET FORTH HEREIN, AS TO TITLE AND AS SPECIFICALLY REQUIRED BY LAW, THERE ARE NO OTHER WARRANTIES, OR ANY AFFIRMATIONS OF FACT OR PROMISES BY BROADCAST ELECTRONICS, WITH REFERENCE TO THE EQUIPMENT, OR TO MERCHANTABILITY, FITNESS FOR A PARTICULAR APPLICATION, SIGNAL COVERAGE, INFRINGEMENT, OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION OF THE EQUIPMENT ON THE FACE HEREOF.



## IMPORTANT INFORMATION

### EQUIPMENT LOST OR DAMAGED IN TRANSIT

When delivering the equipment to you, the truck driver or carriers' agent will present a receipt for your signature. Do not sign it until you have:

1) Inspected the containers for visible signs of damage and 2) Counted the containers and compared with the amount shown on the shipping papers. If a shortage or evidence of damage is noted, insist that notation to that effect be made on the shipping papers before you sign them.

Further, after receiving the equipment, unpack it and inspect thoroughly for concealed damage. If concealed damage is discovered, immediately notify the carrier, confirming the notification in writing, and secure an inspection report. This item should be unpacked and inspected for damage WITHIN 15 DAYS after receipt. Claims for loss or damage will not be honored without proper notification of inspection by the carrier.

### RF PRODUCT TECHNICAL ASSISTANCE, REPAIR SERVICE, PARTS -

**Technical** assistance is available from Broadcast Electronics by letter, prepaid telephone or E-mail. Do not return any merchandise without first contacting Broadcast Electronics and receiving prior written approval and a Return Authorization. We will provide special shipping instructions and a code number that will assure proper handling and prompt issuance of credit. Please furnish complete details as to the circumstances and reasons when requesting return of merchandise. Equipment requiring repair or overhaul should be sent by common carrier, prepaid, insured, and well protected. If proper shipping materials are not available, contact the RF Technical Services department for a shipping container. We can assume no liability for inbound damage, and necessary repairs become the obligation of the shipper. All returned merchandise must be sent freight prepaid and properly insured by the customer

Emergency and warranty replacement parts may be ordered from the following address. Be sure to include the equipment model number, serial number, part description, and part number. Non-emergency replacement parts may be ordered directly from the Broadcast Electronics stock room (see next page.)



## RF TECHNICAL SERVICES

Telephone: +1 (217) 224-9617  
E-Mail: [rfservice@bdcast.com](mailto:rfservice@bdcast.com)  
Fax: +1 (217) 224-6258

## FACILITY CONTACTS

Broadcast Electronics, - Quincy Facility  
4100 N. 24th St. P.O. BOX 3606  
Quincy, Illinois 62305  
Telephone: +1 (217) 224-9600  
Fax: +1 (217) 224-6258  
General E-Mail: [bdcast@bdcast.com](mailto:bdcast@bdcast.com)  
Web Site: [www.bdcast.com](http://www.bdcast.com)

## PARTS

Telephone: +1 (217) 224-9617  
E-Mail: [parts@bdcast.com](mailto:parts@bdcast.com)

## RETURN, REPAIR, AND EXCHANGES

Do not return any merchandise without our written approval and Return Authorization. We will provide special shipping instructions and a code number that will assure proper handling and prompt issuance of credit. Please furnish complete details as to circumstances and reasons when requesting return of merchandise. All returned merchandise must be sent freight prepaid and properly insured by the customer.

## MODIFICATIONS

Broadcast Electronics, reserves the right to modify the design and specifications of the equipment in this manual without notice. Any modifications shall not adversely affect performance of the equipment so modified.







## SAFETY PRECAUTIONS

### PLEASE READ AND OBSERVE ALL SAFETY PRECAUTIONS

ALL PERSONS WHO WORK WITH OR ARE EXPOSED TO POWER TUBES, POWER TRANSISTORS, OR EQUIPMENT THAT UTILIZES SUCH DEVICES MUST TAKE PRECAUTIONS TO PROTECT THEMSELVES AGAINST POSSIBLE SERIOUS BODILY INJURY. EXERCISE EXTREME CARE AROUND SUCH PRODUCTS. UNINFORMED OR CARELESS OPERATION OF THESE DEVICES CAN RESULT IN POOR PERFORMANCE, DAMAGE TO THE DEVICE OR PROPERTY, SERIOUS BODILY INJURY, AND POSSIBLY DEATH!!



### DANGEROUS HAZARDS EXIST IN THE OPERATION OF POWER TUBES AND POWER TRANSISTORS

The operation of power tubes and power transistors involves one or more of the following hazards, any one of which, in the absence of safe operating practices and precautions, could result in serious harm to personnel.

- A. HIGH VOLTAGE** - Normal operating voltages can be deadly. Additional information follows.
- B. RF RADIATION** - Exposure to RF radiation may cause serious bodily injury possibly resulting in blindness or death. Cardiac pacemakers may be affected. Additional information follows.
- C. HOT SURFACES** - Surfaces of air-cooled radiators and other parts of tubes can reach temperatures of several hundred degrees centigrade and cause serious burns if touched. Additional information follows.
- D. RF BURNS** - Circuit boards with RF power transistors contain high RF potentials. Do not operate an RF power module with the cover removed.

## HIGH VOLTAGE

Many power circuits operate at voltages high enough to kill through electrocution. Personnel should disconnect the primary AC Power when accessing the inside of the transmitter.

## RADIO FREQUENCY RADIATION

Exposure of personnel to RF radiation should be minimized, Personnel should not be permitted in the vicinity of open energized RF generating circuits, or RF transmission systems (waveguides, cables, connectors, etc.), or energized antennas. It is generally accepted that exposure to “high levels” of radiation can result in severe bodily injury including blindness. Cardiac pacemakers may be affected.

The effect of prolonged exposure to “low level” RF radiation continues to be a subject of investigation and controversy. It is generally agreed that prolonged exposure of personnel to RF radiation should be limited to an absolute minimum. It is also generally agreed that exposure should be reduced in working areas where personnel heat load is above normal. A 10 mW/cm<sup>2</sup> per one tenth hour average level has been adopted by several U.S. government agencies including the Occupational Safety and Health Administration (OSHA) as the standard protection guide for employee work environments. An even stricter standard is recommended by the American National Standards Institute which recommends a 1.0 mW/cm<sup>2</sup> per one tenth hour average level exposure between 30 Hz and 300 MHz as the standard employee protection guide (ANSI C95.1-1982).

RF energy must be contained properly by shielding and transmission lines. All input and output RF connections, such as cables, flanges and gaskets must be RF leak proof. Never operate a power tube without a properly matched RF energy absorbing load attached. Never look into or expose any part of the body to an antenna or open RF generating tube or circuit or RF transmission system while energized. Monitor the tube and RF system for RF radiation leakage at regular intervals and after servicing.

## HOT SURFACES

The power components in the transmitter are cooled by forced-air and natural convection. When handling any components of the transmitter after it has been in operation, caution must always be taken to ensure that the component is cool enough to handle without injury.



## Table of Contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Overview</b>                              | <b>1</b>  |
| 1.1      | Instructions                                 | 1         |
| 1.2      | Other Documents                              | 1         |
| 1.3      | Installation and Initial Setup Summary       | 1         |
| 1.4      | Product Specifications                       | 2         |
| 1.5      | Default Operation                            | 7         |
| <b>2</b> | <b>Preparing to Install</b>                  | <b>9</b>  |
| 2.1      | Verify Contents of Shipment                  | 9         |
| 2.2      | Items Sold Separately or Not Supplied        | 10        |
| 2.3      | Tools and Materials                          | 10        |
| 2.4      | Estimated Time for Installation              | 10        |
| <b>3</b> | <b>Installation and Initial Setup</b>        | <b>11</b> |
| 3.1      | Install in Rack                              | 11        |
| 3.2      | Exciter PA RF Drive                          | 11        |
| 3.3      | Transmitter RF                               | 12        |
| 3.4      | AC Power                                     | 12        |
| 3.5      | Broadcast Electronics-Interface Active Stub  | 13        |
| 3.6      | GPIO and Exciter-Transmitter Integration     | 13        |
| 3.7      | Turn on AC                                   | 19        |
| 3.8      | Time and Date                                | 19        |
| 3.9      | Frequency                                    | 20        |
| 3.10     | 100% Peak Modulation                         | 21        |
| 3.11     | Power Set point                              | 21        |
| 3.12     | Primary Audio Source                         | 23        |
| 3.13     | Exciter-Transmitter Integration Settings     | 29        |
| 3.14     | Turn RF Transmission On                      | 30        |
| <b>4</b> | <b>Optional Installation Steps</b>           | <b>31</b> |
| 4.1      | Additional Program Services                  | 31        |
| 4.2      | Ethernet/IP Network                          | 33        |
| 4.3      | Password                                     | 36        |
| 4.4      | Stereo Generation and Stereo Pilot Injection | 37        |
| 4.5      | Pre-Emphasis                                 | 38        |
| 4.6      | Secondary Audio and Silence Timeout          | 39        |
| <b>5</b> | <b>Rear Panel Connections</b>                | <b>40</b> |
| 5.1      | GPIO   | 41        |
| 5.2      | Broadcast Electronics INTERFACE              | 43        |
| 5.3      | ETHERNET                                     | 44        |
| 5.4      | COM IN                                       | 44        |
| 5.5      | COM OUT                                      | 44        |
| 5.6      | AES  | 44        |
| 5.7      | LEFT and RIGHT                               | 44        |
| 5.8      | COMP   | 44        |
| 5.9      | SCA1 and SCA2                                | 44        |
| 5.10     | RDS  | 45        |
| 5.11     | 19 kHz OUT                                   | 45        |
| 5.12     | EXC RF OUT                                   | 45        |
| 5.13     | PA RF IN                                     | 45        |
| 5.14     | RF SAMPLE                                    | 45        |
| 5.15     | RF OUT                                       | 45        |
| 5.16     | 10 MHz IN                                    | 45        |
| 5.17     | 1 PPS IN                                     | 45        |



|           |   |           |
|-----------|---|-----------|
| 5.18      | Extended I/O .....                        | 45        |
| 5.19      | Power Switch .....                        | 46        |
| 5.20      | Ground .....                              | 46        |
| 5.21      | AC Input .....                            | 46        |
| <b>6</b>  | <b>Front Panel Features .....</b>         | <b>47</b> |
| 6.1       | AUDIO .....                               | 47        |
| 6.2       | EXC DRV .....                             | 47        |
| 6.3       | CNTL .....                                | 48        |
| 6.4       | PA .....                                  | 48        |
| 6.5       | PS .....                                  | 48        |
| 6.6       | VSWR .....                                | 48        |
| 6.7       | FAILSAFE .....                            | 48        |
| 6.8       | TRANSMITTER CONTROL CENTER .....          | 48        |
| <b>7</b>  | <b>Theory of Operation .....</b>          | <b>49</b> |
| <b>8</b>  | <b>Transmitter Control Center .....</b>   | <b>53</b> |
| 8.1       | Contrast Control .....                    | 53        |
| 8.2       | <b>f</b> Left Button .....                | 53        |
| 8.3       | <b>g</b> Right Button .....               | 53        |
| 8.4       | <b>h</b> Up Button .....                  | 53        |
| 8.5       | <b>i</b> Down Button .....                | 54        |
| 8.6       | <b>8</b> Return Button .....              | 54        |
| <b>9</b>  | <b>Basic Web Page .....</b>               | <b>59</b> |
| 9.1       | RDS and FSK Setup .....                   | 61        |
| 9.2       | Audio Delay Setup .....                   | 62        |
| <b>10</b> | <b>Enhanced Web GUI .....</b>             | <b>63</b> |
| 10.1      | Login .....                               | 64        |
| 10.2      | Navigation .....                          | 65        |
| 10.3      | Power Amplifier .....                     | 67        |
| 10.4      | Exciter .....                             | 69        |
| 10.5      | Input/Output .....                        | 70        |
| 10.6      | Audio .....                               | 71        |
| 10.7      | Logs .....                                | 72        |
| <b>11</b> | <b>SNMP .....</b>                         | <b>73</b> |
| 11.1      | Authentication .....                      | 73        |
| 11.2      | Objects .....                             | 73        |
| <b>12</b> | <b>Backup Control Modes .....</b>         | <b>74</b> |
| 12.1      | Emergency Control Mode .....              | 74        |
| 12.2      | Standby System Control and Exciter .....  | 74        |
| <b>13</b> | <b>Troubleshooting .....</b>              | <b>75</b> |
| 13.1      | Event Log .....                           | 75        |
| 13.2      | Standby .....                             | 75        |
| 13.3      | Failsafe .....                            | 75        |
| 13.4      | Mute .....                                | 76        |
| 13.5      | Internal Exciter Diagnostics .....        | 76        |
| 13.6      | Power Amplifier Diagnostics .....         | 77        |
| <b>14</b> | <b>Maintenance .....</b>                  | <b>78</b> |
| 14.1      | Clean the Air Filter and Check Fans ..... | 78        |
| 14.2      | Remove the Top Cover .....                | 79        |
| 14.3      | Main Power Supply .....                   | 80        |
| 14.4      | AC Switch .....                           | 82        |
| 14.5      | AC Input and EMI Filter .....             | 85        |
| 14.6      | Fan Power Supply .....                    | 88        |
| 14.7      | Fan .....                                 | 90        |



|       |  |     |
|-------|--|-----|
| 14.8  | Fuse – DC Regulator .....                          | 92  |
| 14.9  | DC Regulator .....                                 | 94  |
| 14.10 | Fuse – Low Voltage .....                           | 96  |
| 14.11 | Fuse – Driver Power Amplifier .....                | 97  |
| 14.12 | Fuse – Final Power Amplifier .....                 | 98  |
| 14.13 | Drive Power Amplifier Part .....                   | 99  |
| 14.14 | Final Power Amplifier Part .....                   | 102 |
| 14.15 | Final Power Amplifier Palate .....                 | 105 |
| 14.16 | Power Amplifier and Low Pass Filter Assembly ..... | 107 |
| 14.17 | Front Panel Display .....                          | 114 |
| 14.18 | Extended I/O .....                                 | 116 |
| 14.19 | Controller Exciter .....                           | 117 |

## Figures

|   |    |
|---|----|
| Figure 1 – STXe 500 .....   | 2  |
| Figure 2 – Rack Mounting .....  | 11 |
| Figure 3 – Exciter RF .....   | 11 |
| Figure 4 –RF Output .....   | 12 |
| Figure 5 – AC Power Input .....   | 12 |
| Figure 6 – Active Stub .....  | 13 |
| Figure 7 – Failsafe to Ground .....                                       | 14 |
| Figure 8 – D-Sub Shell Half .....   | 14 |
| Figure 9 – D-Sub Shell Whole and Nuts .....                               | 14 |
| Figure 10 – GPIO Connector .....  | 15 |
| Figure 11 – 949-4161 Extended I/O Exciter-Transmitter Cable Harness ..... | 16 |
| Figure 12 – Extended I/O Jumper Settings .....                            | 17 |
| Figure 13 – Extended I/O Cable Harness .....                              | 18 |
| Figure 14 – Extended I/O Harness GPIO Connection .....                    | 18 |
| Figure 15 - Rear Panel Features .....                                     | 40 |
| Figure 16 - Standard D-Sub 37 Connector Numbering .....                   | 41 |
| Figure 17 – Front Panel .....   | 47 |
| Figure 18 – STXe 500 System Block Diagram .....                           | 51 |
| Figure 19 – Transmitter Control Center .....                              | 53 |
| Figure 20 – Transmitter Control Center Menus Sheet 1 .....                | 55 |
| Figure 21 – Transmitter Control Center Menus Sheet 2 .....                | 57 |
| Figure 22 – Basic Web Interface Main Page .....                           | 59 |
| Figure 23 – Basic Web Interface Authentication .....                      | 60 |
| Figure 24 – Basic Web Interface PA Page .....                             | 60 |
| Figure 25 – Basic Web Interface Events Page .....                         | 60 |
| Figure 26 – Internal RDS Setup Link .....                                 | 61 |
| Figure 27 – RDS Setup Page .....  | 61 |
| Figure 28 – Audio Delay Web Interface .....                               | 62 |
| Figure 29 – Link from Basic Page to GUI Main Page .....                   | 63 |
| Figure 30 – Enhanced Web Page .....                                       | 63 |
| Figure 31 – GUI Pointer Icons .....                                       | 63 |
| Figure 32 – Login Profile Selection .....                                 | 64 |
| Figure 33 – Password and Log In Window .....                              | 64 |
| Figure 34 – Profile Logged Out .....                                      | 64 |
| Figure 35 – Navigation Bar .....  | 65 |
| Figure 36 – Main Screen .....   | 65 |
| Figure 37 – Block Diagram for Navigation .....                            | 66 |
| Figure 38 – Power Amplifier Page .....                                    | 67 |
| Figure 39 - REF Power vs VSWR Feature .....                               | 68 |
| Figure 40 – Exciter Page .....  | 69 |
| Figure 41 – Input/Output Page .....                                       | 70 |
| Figure 42 – Audio Page .....  | 71 |
| Figure 43 – Logs Page .....   | 72 |
| Figure 44 – SNMP MIB Download .....                                       | 73 |
| Figure 45 – Air Filter Removal .....                                      | 78 |
| Figure 46 – Separated Air Filter .....                                    | 78 |
| Figure 47 – Top Cover .....   | 79 |
| Figure 48 – Main Power Supply .....                                       | 80 |
| Figure 49 – Main PS Wires .....   | 80 |
| Figure 50 – Main PS Chassis Screws .....                                  | 80 |
| Figure 51 – Main PS Internal Thumb Screws .....                           | 81 |



|  |     |
|--|-----|
| Figure 52 – Main PS Extraction.....                    | 81  |
| Figure 53 – Main PS Chassis Section.....               | 81  |
| Figure 54 – AC Switch.....                             | 82  |
| Figure 55 – Back Panel Screws.....                     | 82  |
| Figure 56 – N-Type Connector Nut.....                  | 83  |
| Figure 57 – BNC Connector Nut.....                     | 83  |
| Figure 58 – CPE Screws and Snaps.....                  | 83  |
| Figure 59 – Displaced Back Panel Assembly.....         | 84  |
| Figure 60 – AC Switch Tabs.....                        | 84  |
| Figure 61 – AC Switch Wires.....                       | 84  |
| Figure 62 – AC Input Replacement Parts.....            | 85  |
| Figure 63 – AC Cable Tie.....                          | 85  |
| Figure 64 – Cut Shrink Wrap.....                       | 85  |
| Figure 65 – AC Studs.....                              | 86  |
| Figure 66 – AC Input Screws.....                       | 86  |
| Figure 67 – AC Input Assembly Removal.....             | 86  |
| Figure 68 – Internal AC Connections.....               | 87  |
| Figure 69 – Shrink Wrap.....                           | 87  |
| Figure 70 – Fan Power Supply.....                      | 88  |
| Figure 71 – Fan Power Supply Connectors.....           | 88  |
| Figure 72 – Fan PS Screws.....                         | 88  |
| Figure 73 – Fan PS Extraction.....                     | 89  |
| Figure 74 – Fan.....                                   | 90  |
| Figure 75 – Fan Assembly Extraction.....               | 90  |
| Figure 76 – Fan Connectors.....                        | 90  |
| Figure 77 – Fan Orientations.....                      | 91  |
| Figure 78 – Fan Screws.....                            | 91  |
| Figure 79 – 20A DC Fuse.....                           | 92  |
| Figure 80 – Main PS Chassis Screws.....                | 92  |
| Figure 81 – Main PS Internal Thumb Screws.....         | 92  |
| Figure 82 – DC Regulator Fuse Access.....              | 93  |
| Figure 83 – DC Regulator Fuse Location.....            | 93  |
| Figure 84 – DC Regulator Board Assembly.....           | 94  |
| Figure 85 – DC Regulator Cables.....                   | 94  |
| Figure 86 – DC Regulator Screws.....                   | 94  |
| Figure 87 – DC Regulator Snaps.....                    | 95  |
| Figure 88 – DC Regulator Extraction.....               | 95  |
| Figure 89 – 1.5A Low Voltage Fuse.....                 | 96  |
| Figure 90 – Low Voltage Fuse Location.....             | 96  |
| Figure 91 – 1.5A Driver Amplifier Fuse.....            | 97  |
| Figure 92 – Driver Fuse Location.....                  | 97  |
| Figure 93 – 25A Final Amplifier Fuse.....              | 98  |
| Figure 94 – Final Amplifier Fuse Location.....         | 98  |
| Figure 95 – Driver Stage Power Amplifier.....          | 99  |
| Figure 96 – Driver Amp Location.....                   | 99  |
| Figure 97 – Driver RC Parts.....                       | 100 |
| Figure 98 – Driver with Thermal Compound Applied.....  | 100 |
| Figure 99 – Driver Placement.....                      | 101 |
| Figure 100 – Final PA Input Inductor.....              | 102 |
| Figure 101 – Final PA Output Coaxial Cables.....       | 102 |
| Figure 102 – Final PA Mounting Screws and Washers..... | 103 |
| Figure 103 – Final PA Coaxial Cable Heights.....       | 103 |
| Figure 104 – Power Amplifier Palate.....               | 105 |
| Figure 105 – Palate DC Input.....                      | 105 |

|   |     |
|---|-----|
| Figure 106 – Final RF Output .....                        | 105 |
| Figure 107 – Palate Screws .....                          | 106 |
| Figure 108 – Palate with Thermal Compound .....           | 106 |
| Figure 109 – Palate Coaxial Cable Heights .....           | 106 |
| Figure 110 – Power Amplifier Assembly .....               | 107 |
| Figure 111 – Low Pass Filter Circuit Board Assembly ..... | 107 |
| Figure 112 – Bottom PA Screws .....                       | 108 |
| Figure 113 – Side PA Screw .....                          | 108 |
| Figure 114 – Front PA Screw .....                         | 108 |
| Figure 115 – RF OUT Nut .....                             | 109 |
| Figure 116 – RF Sample Nut .....                          | 109 |
| Figure 117 – PA Assembly Cables .....                     | 109 |
| Figure 118 – CPE Screw and Snap .....                     | 110 |
| Figure 119 – Low Pass Filter Ribbon .....                 | 110 |
| Figure 120 – Low Pass Filter Screws .....                 | 110 |
| Figure 121 – Low Pass Filter Ribbon .....                 | 111 |
| Figure 122 – Low Pass Filter Ribbon Extraction .....      | 111 |
| Figure 123 – Low Pass Filter RF Input .....               | 111 |
| Figure 124 – Final PA Palate RF Output .....              | 112 |
| Figure 125 – Low Pass Filter Nut .....                    | 112 |
| Figure 126 – Low Pass Filter Chassis Section Screws ..... | 112 |
| Figure 127 – Low Pass Filter Chassis Nut .....            | 113 |
| Figure 128 – Chassis Section Screw .....                  | 113 |
| Figure 129 – Front Display Board Assembly .....           | 114 |
| Figure 130 – Front Display Screw .....                    | 114 |
| Figure 131 – Front Display Plug .....                     | 114 |
| Figure 132 – Front Display Left Snaps .....               | 115 |
| Figure 133 – Front Display Right Snaps .....              | 115 |
| Figure 134 – Extended I/O Board .....                     | 116 |
| Figure 135 – Extended I/O Cable .....                     | 116 |
| Figure 136 – Extended I/O Jack Screws .....               | 116 |
| Figure 137 – Controller Exciter Board .....               | 117 |
| Figure 138 – CPE D-Subminiature Jackscrews .....          | 117 |
| Figure 139 – CPE XLR Screws .....                         | 117 |
| Figure 140 – CPE BNC Nuts .....                           | 118 |
| Figure 141 – CPE Cables .....                             | 118 |
| Figure 142 – Main PS AC Wiring .....                      | 118 |
| Figure 143 – CPE Screw .....                              | 119 |
| Figure 144 – CPE Snaps .....                              | 119 |
| Figure 145 – Coaxial Cable Displacement .....             | 119 |
| Figure 146 – Board Extraction .....                       | 120 |





## Tables

|   |    |
|---|----|
| Table 1 - Specifications .....  | 3  |
| Table 2 – 949-4144 Standard Transmitter (BE S-Series) Cable Description ..... | 15 |
| Table 3 – Extended I/O Exciter to Transmitter Cable Description .....         | 16 |
| Table 4 – Extended I/O Jumper Settings.....                                   | 17 |
| Table 5 – GPIO Pins .....   | 41 |
| Table 6 – BEI Pins .....  | 43 |
| Table 7 – Main Page and Common Features.....                                  | 66 |
| Table 8 – Power Amplifier Page Features .....                                 | 67 |
| Table 9 – Exciter Page Features.....  | 69 |
| Table 10 – Audio Page Features .....  | 71 |
| Table 11 – Logs Page Features.....  | 72 |
| Table 12 – Exciter Diagnostics Details .....                                  | 76 |
| Table 13 – PA Diagnostics Details.....  | 77 |





# 1 Overview

The STXe FM Exciter series is designed to provide a cost effective solution for FM broadcast.

## 1.1 Instructions

Use this document as an all-inclusive technical resource for STXe 500 systems. Determine broadcast system scope and design. Follow the detailed installation instructions and interfacing descriptions to integrate the STXe 500 in your broadcast system. Refer to user interface detail sections for descriptions of front panel LED display dynamics, interfacing through the transmitter control center, web page, enhanced web page, SNMP, backup control, and system troubleshooting. Follow detailed maintenance directions and, after troubleshooting and diagnosing failures, follow complete sub-system replacement steps.

Select settings such as frequency, expected output power, Ethernet settings, etc. can be communicated at the time of purchase. After standard preliminary testing of all systems, technicians will use customer settings and verify full system operation under closer conditions compared to the intended installation.

IP network interfacing features are optional, and are only included to the extent of the STXe 500 ETHERNET interface and setup. Network cables and hardware depend on the desired networking setup and are relatively common. Please consult a local IT professional if more is needed.

## 1.2 Other Documents

See the STX CPE Software Update Application Guide 597-4200 for software and firmware update details.

Transmitter operation details are not included in the scope of this manual. For electronic copies of these and other Broadcast Electronics technical documentation please visit <http://www.bdcast.com/information-center/>.

## 1.3 Installation and Initial Setup Summary

All of the following steps are required to get a standard STXe 500 system running. This list reflects the headings under the installation and initial setup section:

1. Rack mount
2. Exciter PA RF drive
3. Transmitter RF
4. AC power
5. BE-Interface active stub
6. GPIO Exciter-Transmitter integration
7. Turn on AC
8. Time and date
9. Frequency
10. 100% peak modulation
11. Power setpoint
12. Primary program services
13. Exciter-Transmitter Integration Setup



## 1.4 Product Specifications



Figure 1 – STXe 500

Table 1 - Specifications

| Parameter                 | Specification   |
|---------------------------|---|
| <b>Physical</b>           |   |
| Height                    | 2 RU 3.5" (8.89 cm)   |
| Width                     | 19" (48.3 cm) EIA Rack Mount  |
| Depth                     | 22" (55.9 cm) with connectors, 21" chassis, 25.5" rack  |
| Weight                    | 25lbs (11.3kg) unpacked   |
| Outlet Size               | 66.5 in <sup>2</sup> (429 cm <sup>2</sup> ), rear of unit   |
| <b>Environmental</b>      |   |
| Temperature               | -10°C to +50°C  |
| Altitude                  | 10,000ft (3048M) maximum  |
| Humidity                  | 95% maximum, non-condensing   |
| Air Capacity              | 160 CFM (4.5 m <sup>3</sup> /Min)   |
| Heat Dissipation          | 270 W at Rated Output   |
| BTU                       | 927 BTU/H at Rated Output   |
| <b>AC Input</b>           |   |
| Voltage                   | 90 to 264 VAC Split Phase   |
| Frequency                 | 47-63 Hz  |
| Power Factor              | 0.99 typical at 100V, 0.95 typical at 200V  |
| Surge Protection          | Tested to EN 301 489-1, including voltage dips and dropouts (Section 9.7B), voltage surges (Section 9.8) as well as conducted immunity and conducted radiation. |
| Power Consumption         | 770W (calculated) typical at rated output   |
| <b>RF Output</b>          |   |
| Power Accuracy            | +/-5% of Total Output Power Setting   |
| Asynchronous AM S/N Ratio | 75 dB below rated power reference carrier referenced to 100% peak AM  |
| Synchronous AM S/N Ratio  | 60 dB below rated power reference carrier referenced to 100% peak AM, 75usec de-emphasis, 75 kHz deviation @ 400 Hz Sine  |
| Impedance                 | 50 Ohms nominal   |
| VSWR                      | Rated Power into 1.5:1 VSWR. Open and short circuit protected at all phase angles.  |
| FM Only Power             | 25W-550W  |
| Power Control Precision   | 1W  |
| Efficiency                | 65% typical AC to RF  |
| RF Output Connector       | Type N, Female  |
| <b>Frequency</b>          |   |
| Range                     | 87.5MHz to 108MHz; 10kHz increments   |
| Stability                 | Internal TCXO: +/-100Hz factory calibration, +/-4ppm aging/temp, -10 degrees C to +50 degrees C; External Input: accuracy of reference source                   |



| Parameter                       | Specification  |
|---------------------------------|--|
| <b>Modulation</b>               |  |
| Type                            | 300KF8E<br>Direct-to-channel digitally generated FM (no analog up-conversion); FM only   |
| Capability                      | 300 kHz nominal  |
| Maximum Over                    | 150%   |
| <b>RF Harmonics Suppression</b> |  |
| FCC; DOC; ITU-R; CCIR           | Meets all requirements/recommendations<br>85dB or better typical, low pass filter standard   |
| <b>Composite Input</b>          |  |
| Connector                       | BNC  |
| Impedance                       | 10k ohms, un-balanced  |
| Level                           | 3.5V p-p for 100% modulation   |
| Amplitude Response              | +/-0.03 dB 20 Hz to 53 kHz; +/-0.1 dB 53 kHz to 100 kHz  |
| Phase Response                  | +/-0.1 degree 53kHz to 100kHz  |
| THD + Noise                     | 0.005% or less @ 400 Hz, 10-22Khz bandwidth, 75 uS deemphasis  |
| IMD                             | 0.01% or less SMPTE 60/7000 Hz; 1:1 RATIO<br>0.005% typical DIM-B (14 kHz)   |
| SNR                             | 88dB or better below 100% modulation @ 400Hz, 10Hz-22Khz bandwidth, unweighted<br>95dB typical below 100% modulation @ 400Hz, 10Hz-22Khz bandwidth, A-weighted filter<br>100dB typical below 100% modulation @ 400 Hz, 10Hz-22Khz bandwidth, CCIR-468 filter |
| <b>SCA1 SCA2 RDS Inputs</b>     |  |
| Connectors(2)                   | BNC  |
| Impedance                       | 10k ohms, un-balanced  |
| Level                           | 3.5V p-p for 10% deviation   |
| Response                        | +/-0.1 dB; 53 kHz to 100 kHz   |
| <b>AES Input</b>                |  |
| Connector                       | XLR Female   |
| Impedance                       | 110 Ohms, balanced   |
| Bits                            | 16-24 bits   |
| Rate                            | 32, 44.1, 48, or 96 kHz  |
| Level                           | -2 dBFS default for 100% modulation,<br>Adjustable in 0.1 dBFS steps, -15 dBFS to 0 dBFS   |
| <b>Analog L/R Input</b>         |  |
| Connectors                      | XLR Female   |
| Impedance                       | 600 Ohms or 10K Ohms selectable, balanced  |
| Level                           | 10dBm into 600 Ohms default for 100% modulation<br>Adjustable in 0.25 dB steps, -10dBm to +10dBm   |



| Parameter  | Specification   |
|--|---|
| <b>Stereo Generation (AES and Analog L/R Inputs)</b> |   |
| Modes  | Stereo, Mono L+R, Mono L, Mono R  |
| Pre-emphasis   | None, 50 usec, 75 usec selectable   |
| Amplitude Response                                   | +/-0.25dB; 20 Hz to 15 kHz  |
| THD + Noise  | 0.03 or better @400Hz, measured 10 Hz-22Khz, 75 uS deemphasis                       |
| Mono (L+R):  | 0.005 typical @400Hz, measured 10 Hz-22Khz, 75 uS deemphasis                        |
| Stereo:  | 0.01 typical @400Hz, measured 10 Hz-22Khz, 75 uS deemphasis                         |
|  | 86dB or better below 100% modulation @ 400Hz, 10 Hz-22Khz bandwidth, unweighted     |
|  | 95dB typical below 100% modulation @ 400Hz, 10Hz-22Khz bandwidth, A-weighted filter |
|  | 100dB typical below 100% modulation @ 400 Hz, 10Hz-22Khz bandwidth, CCIR-468 filter |
|  | 90 dB, Stereo 80 dB or better below 100% modulation @ 400 Hz                        |
| IMD  |   |
| Mono (L or R)  | 0.01% or less SMPTE 60/7000Hz; 1:1 RATIO  |
|  | 0.005% typical DIM-B (14kHz)  |
| SNR  |   |
| Mono (L+R):  | 86dB or better below 100% modulation @ 400Hz, 10 Hz-22kHz bandwidth, unweighted     |
| AES:   | 86dB or better below 100% modulation @ 400Hz, 10 Hz-22kHz bandwidth, unweighted     |
| Analog:  | 93dB typical below 100% modulation @ 400Hz, 10Hz-22kHz bandwidth, A-weighted filter |
|  | 98dB typical below 100% modulation @ 400 Hz, 10Hz-22kHz bandwidth, CCIR-468 filter  |
| Stereo:  | 80 dB or better below 100% modulation @ 400 Hz                                      |
|  | Unweighted  |
| Stereo Separation                                    | 70dB or better, 20Hz to 15kHz   |
| AES:   | 80dB typical, 20 Hz to 15 kHz   |
| Analog:  | 76dB typical, 20 Hz to 15 kHz   |
| Crosstalk  |   |
| Linear   | 90dB below 100% typical; Main into Sub or Sub into Main                             |
| Nonlinear  | 80dB below 100% typical; Main into Sub or Sub into Main                             |



| Parameter                       | Specification   |
|---------------------------------|---|
| <b>Pilot Output</b>             |   |
| Connector                       | BNC, un-balanced  |
| Level                           | 1V p-p +/- 5% into high impedance   |
| Stability                       | +/- 300Hz or better on internal reference.<br>+/- 3.0° or better per ITU-R on internal reference.<br>External reference dependent on accuracy of reference source |
| <b>10 MHz Input</b>             |   |
| Connector                       | SMA un-balanced   |
| Level                           | 1 to 3 V p-p, nominal 2.8 V p-p (13 dBm)  |
| <b>1 Pulse Per Second Input</b> |   |
| Connector                       | SMA un-balanced   |
| Level                           | 5V TTL Rising Edge  |
| <b>Regulatory</b>               |   |
| FCC; IC; CE; BETS-6; IEC215     | Meets or exceeds requirements   |





## 1.5 Default Operation

Every STXe 500 Exciter is tested at the factory for quality and reliability. Technicians use settings given to sales representatives at the time of purchase. Unspecified levels are set to nominal levels for testing. Systems are shipped with specified and default settings intact. In the absence of user settings and when a reset to factory defaults command is issued on the front panel user interface, the following default settings are used:

1. Transmitter RF On/Off – Off
2. Frequency – 98.1 MHz
3. Operating Mode – FM Only
4. FM-only Power Set point – Nominal system rating 500W
5. Digital-only Power Set point – 30% of nominal 150W
6. FM+Digital Power Set point – 70% of nominal 350W
7. Sideband power level – -20 dBc
8. Digital PAV – 40V
9. Emergency Output Power – 0 W (disabled)
10. 100% Modulation – 75 kHz
11. Pre-emphasis – None
12. Pilot Injection – On, 10%
13. Mono/Stereo Mode - Stereo
14. Audio Input – Composite
15. AES – -2dBFS input level
16. AES Stereo injection – 100%
17. Analog L – -2.5 dB input gain
18. Analog R – -2.5 dB input gain
19. Analog L/R Stereo injection – 100%
20. Composite – +8.0 dB input gain
21. SCA1
  - o Off
  - o -12.0 dB input gain
22. SCA2
  - o Off
  - o -12.0 dB input gain
23. RDS
  - o Off
  - o -12.0 dB input gain
24. Real Time Clock – shipped with Quincy, IL time, factory reset does not affect this
25. Note: The internal real time clock is likely to have stopped keeping time and reset to 2000-01-01 00:00:00 during shipping or any other time when the system is unpowered for days.

- 26. Controller Ethernet
  - DHCP - Disabled
  - I.P. – 10.2.4.110
  - Subnet Mask – 255.255.0.0
  - Gateway – 10.2.1.1
- 27. VPe Ethernet
  - DHCP - Disabled
  - I.P. – 10.2.4.111
  - Subnet Mask – 255.255.0.0
  - Gateway – 10.2.1.1
- 28. Exgine Ethernet
  - I.P. – 10.2.4.112
  - Subnet Mask – 255.255.0.0
  - Gateway – 10.2.1.1
- 29. All Passwords – 00000000 (invalid)
- 30. AFC Unlock Output Active Level – Low
- 31. Fault Output Active Level – High



## 2 Preparing to Install

The STXe comes with an installation kit. The standard kit provides miscellaneous items that are typically required to interface the STXe 500 as a stand-alone transmitter, or to interface it to a generic transmitter.

There are two other installation kits that can optionally be ordered – one for use with a Broadcast Electronics' S-series transmitter, and one for use with a C- or T-series transmitter. The contents of each installation kit are shown below

### 2.1 Verify Contents of Shipment

|                          | BEI Part #                            | Quantity | Description   |
|--------------------------|---------------------------------------|----------|---|
| <input type="checkbox"/> | 909-4500-C                            | 1        | 500W STXe   |
| <input type="checkbox"/> | 979-4063                              | 1        | STXe 500 Manual Binder                                    |
|                          | <input type="checkbox"/> 597-4063     | 1        | STXe 500 Technical Manual                                 |
|                          | <input type="checkbox"/> 598-0010-001 | 1        | 1" BLUE BINDER  |
| <input type="checkbox"/> | 979-4500-200                          | 1        | Standalone STXe 500 Transmitter Standard Installation Kit |
|                          | <input type="checkbox"/> 417-0284     | 1        | 37PIN D-SUB SHELL   |
|                          | <input type="checkbox"/> 418-0283     | 1        | 37PIN D-SUB FEMALE SOLDERPOT                              |
|                          | <input type="checkbox"/> 420-0007     | 4        | PHILLIPS SCREW 12-24X3/4"                                 |
|                          | <input type="checkbox"/> 420-0710     | 4        | PHILLIPS SCREW 10-32X5/8"                                 |
|                          | <input type="checkbox"/> 421-0002     | 4        | EIA RACK SCREW CLIPS 12-24                                |
|                          | <input type="checkbox"/> 423-1018     | 4        | FIBER WASHER .500X.218X.030                               |
|                          | <input type="checkbox"/> 682-0001     | 1        | AC LINE CORD, AMERICAN                                    |
|                          | <input type="checkbox"/> 682-0003     | 1        | AC LINE CORD, EUROPEAN                                    |
|                          | <input type="checkbox"/> 949-4163     | 1        | BNC CABLE   |
|                          | <input type="checkbox"/> 949-4130     | 1        | EXCITER ACTIVATION STUB                                   |

Alternate installation kit:

|                          |                                   |   |  |
|--------------------------|-----------------------------------|---|--|
| <input type="checkbox"/> | 979-4500-101                      | 1 | STXe 500 Exciter in C or T Series Installation Kit |
|                          | <input type="checkbox"/>          |   | All contents of 979-4500-200 kit (listed above)    |
|                          | <input type="checkbox"/> 949-4161 | 1 | STXe/XMTR INTERFACE HARNESS                        |



## 2.2 Items Sold Separately or Not Supplied

- ☐ Remote station interface controller and wiring for desired connections
- ☐ Networking cable(s) and switch(s) for Ethernet connectivity

## 2.3 Tools and Materials

- ☐ Small flat blade screwdriver (about 5/32" blade or smaller)
- ☐ Large Phillips screwdriver
- ☐ Tie-wraps

### Remote Station Interface Connections

- ☐ Wire - at minimum 2" (5cm), enough for unmute/failsafe jump
- ☐ Wire strippers
- ☐ Soldering iron and solder
- ☐ Heat shrink tubing - recommended to isolate any tightly packed wire connections

## 2.4 Estimated Time for Installation

Installation and initial setup should take approximately 30 minutes.



### 3 Installation and Initial Setup

This section covers installation requirements for a full featured system. Non-standard installations or optional equipment may be covered in other documents.



**ENSURE ALL AC POWER INPUT IS COMPLETELY DISCONNECTED BEFORE ACCESSING ANY SYSTEM COMPONENTS**

#### 3.1 Install in Rack

The STXe 500 fits in two EIA rack units. Rack mounting is highly recommended to maximize safety, quality, and the lifetime of the system; however rack mounting is not absolutely required for operation.

Non-threaded rails: Use provided clips in the lowest and highest holes of the two selected rack units.

Insert four provided screws in felt washers. Prop the STXe500 up in place and secure the system in the rack with the screws as shown in Figure 2.




Figure 2 – Rack Mounting

#### 3.2 Exciter PA RF Drive

Use the provided 949-4163 BNC cable to connect EXC RF OUT to PA RF IN.



Figure 3 – Exciter RF

Systems running with an FW switcher, VPc, or other signal source can skip this step.

### 3.3 Transmitter RF

Connect STXe 500 RF OUT to the transmitter RF input, or for standalone installations simply connect RF out to the antenna transmission line.



Figure 4 –RF Output

### 3.4 AC Power

Connect AC power from the transmitter, or use one of the provided AC power cables to plug into a power socket at the installation facility.



Figure 5 – AC Power Input

### 3.5 Broadcast Electronics-Interface Active Stub

Connect the provided exciter activation stub. Secure the two jackscrews with a small flat screwdriver.



**Figure 6 – Active Stub**

This stub should be set aside and stored in a safe place when system options that utilize this input are included in the broadcast system, for example FW-LP1 switcher and VPc signal generator.

### 3.6 GPIO and Exciter-Transmitter Integration

The STXe provides inputs and outputs that the customer can use to integrate the Exciter with a transmitter and/or a remote monitoring system. These are available on the rear connector labeled "GPIO".

To facilitate connection to the GPIO pins, all installation kits include a loose 37PIN female D-Subminiature solder-pot connector (BE #418-0283) and a shell (BE #417-0284) for the solder-pot connector.

Optional kits which include a wire harness are built with a similar solder-pot connector, to allow the customer to make additions and modifications.

Advanced setups require site engineering. This service is not supported as part of standard system packages. These setups include any physical remote station controller wire connections and transmitter interfacing. See section 5.1 for a detailed explanation of each input and output.

There are three installation types for the STXe 500: 1) Standalone, 2) Active Low/Ground logic, 3) Active High/+5V logic. Depending on which type of installation, follow the instructions in section 3.6.1, 3.6.2 or 3.6.3 below

#### 3.6.1 Basic / Standalone

All installations require the unmute/failsafe input to be grounded. Typically this input should be connected to antenna/load switch interlocks, etc. to assure that the transmitter will only operate when safe.

If operating in a standalone mode without external interlocks, the failsafe input can be wired to the ground pin on the GPIO connector as follows:

1. Connect unmute/failsafe pin 2 (left connection in Figure 7) to ground pin 19 (right connection in Figure 7) through a failsafe relay



**Figure 7 – Failsafe to Ground**

2. Insert the connector on one of the shell halves.



**Figure 8 – D-Sub Shell Half**

3. Place the other shell half on top and set the nuts in place as indicated in the figure.



**Figure 9 – D-Sub Shell Whole and Nuts**

4. Thread the screws through the nuts by inserting up from the bottom.
5. Turn the assembly over and tighten with a small flat screwdriver.
6. Plug the assembly on the GPIO connection and secure the screws.





Figure 10 – GPIO Connector

### 3.6.2 FM-Only S Series Transmitter Interfacing

If interfacing the STXe to a Broadcast Electronics S-series transmitter, the cable harness BE #949-4144 should be used. This harness provides a direct connection from the GPIO on the STXe to the control interface on the S-series transmitter.

This harness can also be used for other manufacturers' transmitters that make use of active low/ground signals.

Table 2 – 949-4144 Standard Transmitter (BE S-Series) Cable Description

| STXe 500 GPIO |            |                 |      | Transmitter Main Exciter Interface |            |                   |      |
|---------------|------------|-----------------|------|------------------------------------|------------|-------------------|------|
| 37-Pin D      | Wire Color | Function        | Dir. | 9-Pin MR                           | Wire Color | Expected Function | Dir. |
| 33            | GREEN      | Forward Power   | Out  | 1                                  | GREEN      | Forward Power     | In   |
| 15            | ORANGE     | Reflected Power | Out  | 2                                  | ORANGE     | Reflected Power   | In   |
| 2             | WHITE      | Failsafe/Unmute | In   | 3                                  | WHITE      | Unmute            | Out  |
| 25            | YELLOW     | AFC Lock        | Out  | 4                                  | YELLOW     | AFC               | In   |
| 20            | RED        | General Fault   | Out  | 5                                  | RED        | Over-Temperature  | In   |
| 19            | BLACK      | Ground          | N/A  | 6                                  | BLACK      | Ground            | N/A  |
| 31            | BLUE       | HD Pwr Cntrl    | In   | 7                                  | BLUE       | HD Pwr Cntrl      | Out  |
| Other         | N/A        | No Connection   |      | Other                              | N/A        | No Connection     |      |

### 3.6.3 Active High/+5V Interfacing through Extended I/O

For installations and transmitters that require active high control logic, such as Broadcast Electronics' C- and T-series transmitters, the extended I/O interface must be used.

The Extended I/O interface cable harness (BE #949-4161) provides a direct connection between the STXe and a C- or T-series transmitter.

This cable harness also has a 9-pin MR connector for use with Broadcast Electronics VPe/XG systems. For FM-only operation, this connector can remain unconnected.

The extended I/O board, in conjunction with the 949-4144 transmitter-Exciter interface cable, allows the STXe to directly replace an FXi Exciter.



**Figure 11 – 949-4161 Extended I/O Exciter-Transmitter Cable Harness**

**Table 3 – Extended I/O Exciter to Transmitter Cable Description**

| Pin   | Direction     | Name            | Description   |
|-------|---------------|-----------------|---|
| 1     | Out from STXe | AFC Lock        | Active when 10MHz reference (internal or external) reports that it is locked. High/Low active behavior can be selected by jumper setting on the extended I/O board. |
| 2     | N/A           | Ground          | Chassis ground connection.  |
| 3     | Out VPe       | HD Status       | Indicates missing status of digital carriers when digital carriers are turned off or missing due to a detected fault/failure.                                       |
| 4     | Out VPe       | Reserved        | Reserved  |
| 7     | In CPE VPe    | Reset           | Active low Causes a hardware reset in CPE and VPe systems.  |
| 8     | Out CPE       | Fault           | Active when a fault is detected. High/Low active behavior can be selected by jumper on the extended I/O board.  |
| 9     | Out CPE       | Forward Power   | Forward power out GPIO pin  |
| 10    | Out CPE       | Reflected Power | Reflected power out pass-through.   |
| 14    | In CPE VPe    | Failsafe/Unmute | Assert active low to enable the Transmitter/Exciter.  |
| 15    | In CPE VPe    | Mute            | Assert active low to mute and disable the Transmitter/Exciter RF outputs.   |
| 23    | In CPE        | Power Control   | Analog 4-state power control for use in FMI digital transmitter systems. 0-0.75V mute, 0.75V-2V lower power, 2-3V hold, 3-5V raise.power                            |
| 24    | N/A           | Ground          | Chassis ground connection.  |
| 25    | N/A           | Ground          | Chassis ground connection.  |
| Other | N/A           | N/A             | No Electrical Connection  |

1. Change jumper settings to match the intended setup. This requires access to the interior of the system. Refer to section 14.2 for steps to remove the top cover. Also see section 3.13 regarding outputs that can be set to active high/low front panel configuration.




Figure 12 – Extended I/O Jumper Settings

Table 4 – Extended I/O Jumper Settings

| Jumper | Position 1-2  | Position 2-3   |
|--------|---|--|
| J2     | DEFAULT and "T Series" configures failsafe/unmute, mute, and reset inputs to be active low logic.                               | "S/C Series" configures failsafe/unmute, mute, and reset inputs to be active high logic. |
| J3     | DEFAULT " + 5V configures HD Status Output to be active low logic.  | "GND" configures HD Status Output to be active high logic.                               |
| J6     | "T Series configured for IBOC only" routes 4-state power control input to an (optional) internal voltage-controlled attenuator. | DEFAULT, "S/C Series" and "T Series Analog", routes 4-state power control input to CPE.  |

2. Connect the labeled 25-pin harness plug to the Extended I/O jack and secure it with a small flat screwdriver.



**Figure 13 – Extended I/O Cable Harness**

3. Connect the 37-pin plug to the GPIO jack and secure it with a small flat screwdriver.



**Figure 14 – Extended I/O Harness GPIO Connection**

4. Connect the 25-pin transmitter control cable (previous connected to FXi remote J7 jack) to the 25-pin cable harness connection and secure the screws
5. The cable harness also includes a 9-pin MR connection to integrate the optional VPe system with transmitters through a cable-to-cable connection. This connector is intended to remain disconnected in FM-only system installations


### 3.7 Turn on AC

1. Unlock AC main breaker on the service line and turn AC service switches to the on position.
2. Turn on all transmitter circuit breakers (if standalone skip this step).
3. Flip the Power Switch to the on position on the STXe 500 unit.

### 3.8 Time and Date

The internal real time clock holds the current time and date for use in the event log. This device supports 24-hour format and does not adjust for daylight savings time. If installing during summer in a daylight savings region, following standard time is recommended. Alternatively, the clock can be set to UTC


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the Date and Time menu. Press enter to continue.



2. Press up or down to select the time editing screen.



3. Set the local (24 hour non-daylight saving) time. Press left or right to move the cursor and press up or down to increment or decrement the number.




4. Press enter when finished editing for the setting to take effect in the system, save, and start keeping time.

5. Enter the date and time menu again. Press up or down to navigate to the date editing screen.



6. Set the current date. Press left or right to move the cursor and press up or down to increment or decrement the number.




7. Press enter when finished editing for the setting to take effect in the system, save, and keep time.

### 3.9 Frequency


STXe systems are frequency-agile. The frequency can be changed directly from the front panel – no hardware modifications or tuning procedure is required when the carrier frequency is changed.

If the STXe RF output is on ("TX ON") when the frequency is changed, the system will momentarily turn the RF output off, change the frequency, and immediately turn RF back on again with the new frequency.

1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the FREQUENCY menu. Press enter to continue.



2. Press left or right to move the cursor between digits. Press up or down on each digit to increment or decrement the number.



3. Press enter when finished editing for the frequency change to take effect.




### 3.10 100% Peak Modulation

The STXe defaults to 100% modulation being +/- 75 kHz. This section only applies if the STXe is being used in an installation where 100% modulation is not +/- 75 kHz.


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.



2. Press up or down to select DEV,( the FM deviation control setting).



3. Press left or right to move the cursor between digits. Press up or down for each digit to increment or decrement the number. This change takes effect while editing, allowing active tuning.




4. Press enter when finished exit the sub-menu.

### 3.11 Power Set point

This section applies to installations where the STXe 500 system is the transmitter or where a fixed power output is required to drive a high power transmitter. Setups where the STXe 500 is an integrated exciter and/or IPA for a transmitter where the transmitter regulates STXe 500 power, can skip this section.


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the PWR SET menu. Press enter to continue.



2. Press up or down to select the power set point for the FM operation mode, which should display as active. Note that digital, FM+digital, and hybrid HD sideband settings require an optional VPc system. Press enter to continue.



3. Press left or right to move the cursor between digits. Press up or down on each digit to increment or decrement the number. Current output forward power measurements are displayed in the lower left of the screen



4. Press enter when finished editing for the new power set point to take effect.





## 3.12 Primary Audio Source


The STXe 500 provides built-in injection of one primary audio source: AES, Analog Composite, AES Composite, or Analog L/R. Supplementary audio sources SCA1, SCA2, and RDS can be enabled and used in any on/off combination with these primary audio sources.

### 3.12.1 AES


The STXe supports standard AES audio as well as 192 kHz Composite over AES. The 192 kHz Composite over AES operates with various brand name systems including Wheatstone, Omnia and Orban audio processors.

To operate Composite over AES, follow the steps below, but select "AES COMP" rather than "AES" as the input.


1. Connect an XLR cable from the desired AES audio source.
2. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO INPUT menu. Press enter to continue.



3. Press up or down to select AES as the primary audio source. Press enter to continue.



4. The screen will display the injection percentage allocated to AES. This setting allows the customer to budget the modulation when supplementary services are present. Leave this at 100% if there are no supplementary services in use. If supplementary services are present, set the total modulation percentage associated with AES. This can be adjusted from 70% to 100%. Use the left and right arrows to move the cursor. Press up or down buttons for each digit to increment or decrement the number



5. Press enter when finished editing for the setting to take effect in the system and save.
6. AES audio levels are expressed in terms relative to Full Scale of the digital signal path selected.


7. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.



8. Press up or down to select "AES". Press enter to continue.



9. The display will show the current peak modulation attributable to the AES input. The level can be adjusted by changing the associated dBFS setting. This has a range of -28.0 dBFS to +0.0 dBFS in 0.1 dB steps. This represents the AES level that will generate the percentage modulation shown on the screen
10. Press left or right to move the cursor. Press up or down on each digit to increment or decrement the number and take effect in the system. This has immediate effect. Do this until the displayed left channel peak hold is the desired value – typically 100%.



11. Press enter when finished editing to exit the sub-menu




### 3.12.2 Analog L/R


1. Connect XLR cables from the desired Analog Left and Right audio sources. Activate the source with constant level tones or typical level audio on each channel.
2. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.



3. Press up or down to select ANLG L/R as the primary audio source. Press enter to continue.




4. Set the stereo injection reduction (to allocate injection budget for supplemental services). Leave this at 100% if there are no supplemental services. Press left or right to move the cursor. Press up or down for each digit to increment or decrement the number.



5. Press enter when finished editing for the setting to take effect in the system and save.
6. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.




7. Press up or down to select L. Press enter to continue.




8. The display will show the current peak modulation attributable to the Left input. The level can be adjusted by changing the associated gain/attenuation. This has a range of -96.0 dB to +22.0 dB in 0.25 dB steps. Press left or right to move the cursor.

Press up or down on each digit to increment or decrement the number and take effect in the system. This has immediate effect. Do this until the displayed left channel peak hold is the desired value – typically 100%.




9. Press enter when finished editing to save the L calibration setting.

10. Repeat these steps 6 - 9 for R.




### 3.12.3 Composite

1. Connect a BNC cable from the desired unbalanced composite audio source. Activate the source with a constant level tone or typical level real audio.
2. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO INPUT menu. Press enter to continue.



3. Press up or down to select COMPOSIT as the primary audio source. Press enter to continue.



4. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.




5. Press up or down to select COMP. Press enter to continue.



6. The display will show the current peak modulation attributable to the Composite input. The level can be adjusted by changing the associated gain/attenuation. This has a range of -96.0 dB to +22.0 dB in 0.25 dB steps. Press left or right to move the cursor. Press up or down on each digit to increment or decrement the number. This has immediate effect. Do this until the displayed peak hold is the desired value – typically 100%.

Note: The Composite input is summed with the supplementary sources SCA1, SCA2, and RDS. When calibrating the Composite input, the supplementary sources should be turned off.



7. Press enter when finished editing to save the Composite setting.



### 3.13 Exciter-Transmitter Integration Settings


Certain outputs from the STXe 500. can be configured as active high or active low. Follow the instructions of this section if the STXe is being interfaced to a transmitter that utilizes active high logic. The outputs that can be configured are: 1) AFC unlock alarm output, and 2) general fault output.

For use with Broadcast Electronics S-, C-, and T-series transmitter the settings should be.:

AFC Lock = Low

Fault Out = High


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the SETUP menu. Press enter to continue.



2. Press up or down to select AFC UNLOCK and press enter to continue.




3. Press up or down to change the selection to HIGH.



4. Press enter for the logic setting to save and take effect in the system.
5. Press enter at < SETUP > again and press up or down to select FAULT OUT.



6. Press up or down to change the selection to HIGH.



7. Press enter for the logic setting to save and take effect in the system.


### 3.14 Turn RF Transmission On

If all setup steps have been completed, including desired optional features in the next section and transmitter setup/integration, the system is ready for operation.


If the STXe 500. is being used as an Exciter for a transmitter, the STXe 500 is controlled by the transmitter; turning the RF on at the transmitter should unmute the STXe500.

If the STXe 500 is being used as a standalone transmitter, follow these steps to turn the RF on

1. At the main screen on the transmitter control center, press the return button.



2. Press the button under "ON" to power up the transmitter.





## 4 Optional Installation Steps

### 4.1 Additional Program Services


The STXe 500 allows operation of three supplementary audio services. These are labelled SCA1, SCA2 and RDS. It is expected that these will be generated by an external system, modulating the audio at the proper frequency between 57 kHz and 100 kHz.

The setup of these audio input sources all follow the same pattern as one another. Repeat these steps below to utilize any of these inputs


1. Connect a BNC cable from the external signal generator source to the supplementary program input. Activate the source with a constant level tone or typical level audio.
2. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the SCA/RDS menu. Press enter to continue.



3. Press up or down to select the desired SCA/RDS input.



4. Press up or down to change the setting to ON.



5. Press enter for the on/off setting to save and take effect in the system.

6. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the AUDIO LEVEL menu. Press enter to continue.




7. Press up or down to select the desired input and press enter to continue.



8. Press left or right to move the cursor. Press up or down on each digit to increment or decrement the number and take effect in the system. Do this until the displayed composite peak hold is within a few percent of 100%.

Note:.. Composite, SCA1, SCA2, and RDS input signals all contribute to this composite peak hold value. Only the source being calibrated should be driven during calibration; the other sources should be turned off

9. Adjust until the displayed composite peak hold is at the level desired for the particular input – typically between 5% and 10%.



## 4.2 Ethernet/IP Network

IP network features are entirely optional. System setup sections below contain procedures based on the LCD interface on the front panel of the main assembly, but there is alternative user interfacing for control of all of these setup parameters in both the web and SNMP interfaces.

The currently used configuration, such as IP address, can be observed in front panel menus. The actual configuration of the system may be determined by DHCP rather than the static settings. Configuration should be made to match whatever network setup is installed.

Consult your network manager or internet service provider to ensure that the correct IP settings are used.

For any network type, connect an Ethernet cable from the ETHERNET port to networking equipment (such as a switch or gateway).


### 4.2.1 Static IP

Use either this simple static IP setup or dynamic host control setup.


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the ETHERNET/IP menu. Press enter to continue.



2. Press up or down to select the port to be set up. CONTROLLER is the ETHERNET port on the STXe 500. Engine is the ETHERNET DATA port on the optional VPe/XG system. VPe is the ETHERNET VPE port on the optional VPe/XG system. Press enter to continue.



3. Press up or down to select the IP parameter to be observed or changed. Press enter to continue.



- This level displays the current state of the IP port, which includes DHCP, IP address, subnet mask, gateway address, and MAC address. Press up or down to observe the currently active IP configuration (0.0.0.0 IP address typically indicates that the port is not connected), and then press enter to modify the static IP setting.

|  |  |
|--|--|
| <p>TRANSMITTER CONTROL CENTER</p> <p><b>IP ADDRESS</b></p> <p>010.002.004.110</p>      | <p>TRANSMITTER CONTROL CENTER</p> <p><b>SUBNET MASK</b></p> <p>255.255.000.000</p> |
| <p>TRANSMITTER CONTROL CENTER</p> <p><b>GATEWAY ADDRESS</b></p> <p>010.002.001.001</p> | <p>TRANSMITTER CONTROL CENTER</p> <p><b>MAC ADDRESS</b></p> <p>AABBCCDDEEFF</p>    |

- Press left or right to move the cursor to any of the 12 digits. Press up or down to increment or decrement the number. Press enter when finished making the setting change.

TRANSMITTER CONTROL CENTER

192.168.001.010

^

- Verify that the settings active by connecting to the port.

#### 4.2.2 Dynamic Host Control

Dynamic IP setup using DHCP is appropriate for more sophisticated and secure network setups. Ethernet will not function when DHCP is enabled and a DHCP-based host controller (typically an internet gateway) is missing from the network setup.

Use either this dynamic host control setup or static IP setup.

- From the main screen on the transmitter control center on the front panel of the main assembly, navigate to the ETHERNET/IP menu. Press enter to continue.

TRANSMITTER CONTROL CENTER

< ETHERNET/IP >

- Press up or down to navigate to the ETHERNET/IP CONTROLLER. Press enter to continue.

TRANSMITTER CONTROL CENTER


ETHERNET/IP  
CONTROLLER




3. Once in the menus, press up or down to select CONTROLLER DHCP and press enter.



4. Once in the menu, press up or down to select DHCP and press enter.



5. Press up or down to change the selection to ENABLED and press enter.



6. Verify that the host control function is active by connecting to the IP port with a web browser. Connect through the managed switch/gateway. Alternatively, view the IP ADDRESS status in these menus to retrieve the current host and access the port through a different local switch.

### 4.3 Password

The default password is invalid for control access. One or more of the passwords (operator, user, or chief) must be set to be used to control the system through any IP interfaces.


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the PASSWORD menu. Press enter to continue.



2. Press up or down to select the password to be set. Press enter to continue.



3. Press left or right to move the cursor between password digits. Press up or down on each digit to increment or decrement the number password.




4. Press enter when finished editing for the password to take effect in the system.




#### 4.4 Stereo Generation and Stereo Pilot Injection

Internal stereo generation utilizing the AES or Analog L/R audio input channels is optional.

1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the MONO/ST MODE menu. Press enter to continue.




2. Press up or down to select STEREO.




3. Press enter for the selected mono/stereo mode to save and take effect in the system.

Note that if changing from any mono mode to stereo, the internally generated 19kHz stereo pilot will automatically turn on at the previously set level. Change back to mono from stereo automatically turns the stereo pilot off.


4. To change the injection of the 19kHz stereo pilot: from the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the MONO/ST MODE menu. Press enter to continue.



5. Press up or down to select LEVEL.



6. Set the injection level of the pilot in the stereo signal. The percentage of peak injection is relative to the AES or Analog L/R level. If the AES level is set to 70% reduction factors, a pilot level setting of 10% would cause 7% deviation. Press left or right to move the cursor. Press up or down to increment or decrement the number.




7. Press enter for the pilot level to save and take effect in the system.

The Pilot has two modes of operation: 1) On, or 2) Stereo. When the On mode is selected, the 19 kHz pilot will always be present. If in Stereo mode, the Pilot will only be present if the STXe is in Stereo mode.


## 4.5 Pre-Emphasis

Internal pre-emphasis filtering on the AES and Analog L/R audio inputs is another standard option feature tied to internal stereo generation. North American receivers are typically compatible with 75 microsecond filters while European receivers typically utilize 50  $\mu$ s.

1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the pre-emphasis menu. Press enter to continue.



2. Press up or down to select the desired filter type.



3. Press enter for the filter change to save and take effect in the system.





## 4.6 Secondary Audio and Silence Timeout

The SECONDARY AUDIO feature allows switching to an alternate source after the PRIMARY AUDIO is absent for the time entered in the SILENCE TIMEOUT setting.


1. From the main screen on the transmitter control center on the front panel of the main assembly, press up or down to navigate to the SETUP menu. Press enter to continue.




2. Press up or down to select the secondary audio to be set. Press enter to continue.




3. Press up or down to select one of the 4 inputs; Composite, Analog L/R, AES, AES Composite, or None if secondary audio isn't used. Injection level setup for Secondary Audio will be same as outlined in section 3.12.



4. Press enter when finished with selection for the secondary audio source to take effect in the system.
5. Press SET UP again.
6. Press up or down to select SILENCE TIMEOUT and press enter to continue.



7. Press up or down, left or right to enter a timeout in seconds.



8. Press enter when finished for the time out setting to take effect in the system.

## 5 Rear Panel Connections

Before installing the STXe 500, please take some time to familiarize yourself with all of the connectivity features included in STXe.

Logic “low” refers to a connection to within 0.8V of isolated ground. The logic “High” level is a connection to a voltage greater than 2.4V compared to the isolated ground. A floating input is at the logic “High” level due to internal pull-up resistors on the inputs. Inactive inputs should be left open/floating and not driven. The STXe has active Low inputs. (Refer to section 3.6 for systems requiring active High inputs.) That is, when a pin is grounded, it is asserted.

Active edge refers to a transition from the inactive state to the active state and the implication is that no action is performed on the transition back to high. A momentary input pulse on an active edge input should be at least 100ms in duration to ensure capture of the event.

Active low refers to an application of the low state. The STXe will treat the input as active as long as it is held low.

The reference designators in the figure below refer to sub-section numbers. For example, flag 1 corresponds to details in section 5.1.





Figure 15 - Rear Panel Features



**THIS SYSTEM USES CMOS LOGIC ON "GPIO" AND "BE INTERFACE" CONNECTIONS. LOGIC VOLTAGES THAT EXCEED +5V WILL DAMAGE CIRCUITRY. THIS TYPE OF DAMAGE REQUIRES HARDWARE SERVICE AT THE USER'S EXPENSE AS THE WARRANTY ON THIS SYSTEM WILL BE VOID!**

## 5.1 GPIO

General Purpose Input/Output Connector. This D-Sub 37 male connector is used in remote station interface control and other machine interfacing. Pin descriptions are described in detail in Table 5.



**Figure 16 - Standard D-Sub 37 Connector Numbering**

**Table 5 – GPIO Pins**

| Pin | Direction | Name                    | Description   |
|-----|-----------|-------------------------|---|
| 1   | Input     | Fault Reset             | Resets all the transmitter faults with an active low edge.  |
| 2   | Input     | Failsafe                | Transmitter failsafe input. Requires a sustained low to run RF in the system.   |
| 3   | Input     | Transmitter On          | Turns RF power on with an active low edge.  |
| 4   | Input     | Transmitter Off         | Turns RF power off with an active low edge.   |
| 5   | Input     | Mute                    | Mutes RF while the input is held low. This essentially performs the function of "Transmitter Off" when held low.  |
| 6   | Input     | Raise Transmitter Power | Raises the system power 1 Watt every second that this input is held low.  |
| 7   | Input     | Lower Transmitter Power | Lowens the system power 1 Watt for every second that this input is held low.  |
| 8   | Input     | Reserved                | Reserved  |
| 9   | Input     | Controller Reset        | Forces hardware reset on the System Controller and Exciter when active. . Note: this input is not intended to be used during normal operation of the system and should only be used in extreme circumstances. |
| 10  | Input     | Reserved                | Reserved  |
| 11  | Input     | Reserved                | Reserved  |
| 12  | Input     | Ground                  | Alternative isolated ground pin internally connected to pin 19, see below for details.  |
| 13  | Input     | Reserved                | Reserved  |
| 14  | Input     | VPe System Present      | Indicates the presence of a VPe system in the setup..   |
| 15  | Output    | Reflected Power         | DC voltage for total reflected power at the system RF output. Can be set up to vary linearly from 0V = 0W to 5V = 8 Watts or logarithmically to drive a T-series meter  |
| 16  | Output    | PA Total Current        | DC voltage for total RF power supply current for PA module. Varies linearly from 0 = 0A to 5 V = 30 A.  |

| Pin | Direction | Name               | Description  |
|-----|-----------|--------------------|--|
| 17  | Output    | PA Temperature     | DC voltage for heat sink temperature reading in PA module. Varies linearly from 0V = 0 degrees C to 5V = 100 degrees C.  |
| 18  | Input     | Reserved           | Reserved   |
| 19  | N/A       | Ground             | Isolated ground intended to be used for safe remote input logic connections on this interface. Jumper J9 on the 919-4200-100 board allows this to be wired to a system-wide chassis ground. Internally connected Pin 12. |
| 20  | Output    | General Fault      | Low when any fault is active in the system. Can be setup to be active High.  |
| 21  | Output    | VSWR Fault         | Low when any part of the system is shut down due to reflected power above safe levels or VSWR greater than 2.0:1   |
| 22  | Output    | Transmitter On     | Low when system RF output power is on.   |
| 23  | Output    | Transmitter Off    | Low when system RF output power is off.  |
| 24  | Output    | Mute Status        | Low when the transmitter is muted via input pin 5.   |
| 25  | Output    | AFC Lock           | Low when the internal Exciter is locked onto the set frequency. Can be setup to be active High.  |
| 26  | Output    | Power Supply Fault | Low when a power supply fault is detected in any RF power supply.  |
| 27  | Output    | Reserved           | Reserved   |
| 28  | Output    | PA Fault           | Low when any fault is detected in any PA module.   |
| 29  | Output    | Reserved           | Reserved   |
| 30  | Output    | Reserved           | Reserved   |
| 31  | Input     | Raise/Lower        | This is only utilized in FM+Dig and Dig only Exciter system configurations. FMI-transmitter four-state power control input: 0-0.75V mute, 0.75-2V lower, 2-3V hold, 3-5V raise   |
| 32  | Output    | +5V                | DC voltage for system forward output power. Can be set up to vary linearly from 0V = 0W to 5V = 70 Watts, or logarithmically to drive a T-series meter.  |
| 33  | Output    | Forward Power      | DC voltage for system forward output power. Varies linearly from 0V = 0W to 5V = 550 Watts   |
| 34  | Output    | PA Voltage         | DC voltage representing the variable RF power supply. Linear from 0V = 0V to 5V = 60V.   |
| 35  | Output    | Reserved           | Reserved   |
| 36  | Output    | Reserved           | Reserved   |
| 37  | N/A       | Ground             | Chassis ground   |



## 5.2 Broadcast Electronics INTERFACE

Broadcast Electronics machine interface. This D-Sub 37 female connector provides conduits for many exciting new product options including a standby exciter, digital radio generators, and much more.

**Table 6 – BEI Pins**

| Pin   | Direction | Name           | Description  |
|-------|-----------|----------------|--|
| 2     | N/A       | Ground         | Chassis Ground   |
| 4     | Input     | Active/Standby | Tie to ground to activate this CPE for normal operation. Open for standby required for firmware updates. |
| Other |           | Reserved       | Reserved   |



### 5.3 ETHERNET

Ethernet is provided on a standard 10/100 Mbps RJ45 connector. Connect to a local area network switch and/or to a gateway using Cat5E cable for access through the network. This interface automatically negotiates speed and hardware interfacing; a crossover cable is not required. Direct connections to a PC or other network controller can be made with either a crossover or straight Ethernet cable.

IP-based interfaces such as the built-in website and SNMP require this to be connected and the network parameters set up through the front panel interface. There is no explicit limit on the number of concurrent users that can be connected to the STXe; however an excessive number of connections will cause a decrease in performance

### 5.4 COM IN

This input is not used in typical STXe applications at this time. Connecting to this jack may cause internal system communications failures.

### 5.5 COM OUT

This output is not used in typical STXe applications at this time. Connecting to this jack may cause internal system communications failures.

### 5.6 AES

AES/EBU audio input connector. This XLR connector is used for inputting digital audio to the standard stereo generator in the internal exciter. Select AES or AEX Comp as the primary audio source to modulate RF with this audio.

Supported bitrates include 32, 44.1, 48, 96, and 192 KSPS.

### 5.7 LEFT and RIGHT

Left and Right balanced analog audio input connectors. These XLR connectors input audio into the standard stereo generator system in the internal exciter. Set Analog L/R as the primary audio source in order to modulate RF with this audio.

An internal hardware jumper allows these inputs to be switched between 600 Ohm or 10k Ohm impedance.

### 5.8 COMP

Unbalanced composite audio input connector. This BNC connector allows input of baseband audio up to 100 kHz into the internal exciter. Setting Composite as the primary audio source modulates RF with this signal.

### 5.9 SCA1 and SCA2

Subsidiary Communications Authorization audio input connectors. These BNC connectors allow subcarrier programs up to 100 kHz generated by external devices to be injected in the internal exciter. These inputs are enabled and disabled independently.



## 5.10 RDS

Radio Data System input connector. This BNC connector allows input of an externally generated RDS standard signal to broadcast time, station identification, and program service information. This input is enabled and disabled independently.

## 5.11 19 kHz OUT

This is a 19 kHz stereo pilot output connector. This BNC connector is used to output the pilot signal for optional use in external synchronization equipment. The output wave form is a constant 1 V peak-to-peak sinusoid when connected to a high impedance termination.

## 5.12 EXC RF OUT

Internal exciter RF output connector. This BNC connector outputs the internally generated exciter power level RF signal.

## 5.13 PA RF IN

Power Amplifier RF Input BNC connector. This is connected to the EXC RF OUT for FM operation. It is connected to the optional VPe/XG if in a Digital mode, (e.g. HD radio or Digital Radio Mondiale).

## 5.14 RF SAMPLE

Power amplifier RF sample output connector. This BNC carries a coupled RF signal from the PA. Nominally generates about 19 dBm at about 500W PA output power. The output level scales with total output power of the PA module. This not a calibrated output.

## 5.15 RF OUT

Power Amplifier RF output connector. This N-connector output carries the amplified RF output. Connect this output to a 50 Ohm load.

## 5.16 10 MHz IN

This is a 10 MHz clock input connector. This BNC synchronizes the exciter's internal clocking to a connected sinusoidal clock signal. This may optionally be connected to a high precision clock generator such as a GPS receiver module or a digital or digital radio signal generators.

## 5.17 1 PPS IN

The one pulse-per-second BNC input connector synchronizes stereo pilot signals such that rising zero-crossing point in the pilot signal corresponds to the rising edge of this logic clock. This may optionally be connected to a high precision clock generator such as a GPS receiver module or a digital radio signal generator.

## 5.18 Extended I/O

Interface specifically designed for legacy Broadcast Electronics transmitter integration. See section 3.6 for details.



## 5.19 Power Switch

AC power switch. This hand operated switch turns on or off power service to the device. Complete power-down of the module may take a few seconds.

## 5.20 Ground

Ground bolt that should be used to connect chassis ground to the transmitter station ground.

## 5.21 AC Input

This is the AC power input jack. Use the provided AC power cord to plug into a standard AC outlet, or create a custom cable for 220 single phase service.





## 6 Front Panel Features

The main assembly front panel contains LED indicators for the system controller, internal exciter, internal power amplifier, and an LCD user interface.




Figure 17 – Front Panel

### 6.1 AUDIO

The audio LED indicates the status of the current primary audio source and remains green until a fault is detected. If an audio peak is detected, this LED turns red and also during a silence condition when no secondary audio is setup. If a secondary audio source is setup, the LED will turn orange after the primary silence timeout. The LED will return to green when the fault is cleared and the exciter switches back to primary. Check the exciter diagnostics for details on what alarms or faults may be active.

### 6.2 EXC DRV

The exciter drive LED indicates the status of any alarms or faults related to the exciter or exciter drive in an internal PA. Green indicates that the exciter has settled into normal operating conditions. Orange indicates an alarm condition. Red shows when the exciter has a fault condition. See Table 12 – Exciter Diagnostics Details in section 13.5 for more information.

Note that there is overlap between internal exciter and internal PA status for drive detection. An exciter drive alarm indication may originate in measurements within the PA.

### 6.3 CNTL

The system control LED shows the status of the system controller. Green indicates normal control operation. Red indicates a loss of monitoring and control communication between controller units. This could be between the system controller and the front panel display, any PA controller, or the combiner controller.

### 6.4 PA

The power amplifier LED shows status of the internal PA. Green indicates normal operation. Orange indicates an alarm condition. Red indicates a fault and PA shutdown condition. Table 13 – PA Diagnostics Details in section 13.6 for details on what alarms or faults may be active.

### 6.5 PS

The power supply LED shows the status of the RF power supply module. Green indicates normal operation. Orange indicates a self-reported alarm. Red indicates a determined fault. Check PA diagnostics for details on what alarms or faults may be active in the supply connected to the PA.

Note that these power supplies are on the same communications node as the PA they are paired with. A communication fault will illuminate red on both the PA and the PS LEDs.

### 6.6 VSWR

The voltage standing wave ratio LED shows the status of the internal PA output in terms of measured reflected power. Green indicates normal operation into an acceptable load. Orange indicates active foldback protection. Red indicates a fault and shutdown condition.

### 6.7 FAILSAFE

The failsafe LED is coupled to the failsafe input on the back panel when running transmitter modes. Green indicates the failsafe is connected for normal operation. If red the failsafe is not connected and RF power will not turn on.

In exciter setups this LED is turned off.

### 6.8 TRANSMITTER CONTROL CENTER

This front panel LCD interface can be used for control and monitoring of all features in the system. Use the five buttons below the screen to navigate and make modifications. See section 8 - Transmitter Control Center, for details on how to use this interface.



## 7 Theory of Operation

Refer to the system block diagram in Figure 18 on the page following.

Broadcast Electronics STXe FM transmission systems are equipped with a system controller and exciter platform. The exciter sub-system routes audio and other program service data through digital signal processing, digital up conversion, a numerically controlled oscillator, RF digital to analog conversion, and low-power RF analog signal output. This signal path generates a frequency modulated carrier waveform centered within the traditional FM band.

A micro-controller provides user interfacing (including IP), regulates all signal path stages in the exciter, and negotiates control and monitoring with PA controller and front panel interface controller peripheral micro-control modules through controller area network CAN communications.

STXe systems include numerous built-in safety features. Hardware failsafe can be used to reliably disable RF with external automated or manual controls. Automatic RF power fold-back, and system shutdown mechanisms protect power amplification in events of DC over-currents, excessive reflected RF power, or dangerously high internal temperatures. Dedicated circuits immediately mitigate unsafe conditions while micro-controllers self-determine system problems, take action as necessary, report faults/alarms, and log issues for troubleshooting.

In standard setups, exciter RF is routed from lower power exciter RF output back into the system in order to drive RF power amplification. Operating mode setup parameters determines the definition of this interface, which is described in following paragraphs.

Systems come standard equipped to run either of two standard modes of power amplification. FM-only mode utilizes a fixed exciter RF drive level. Variable final amplifier voltages compress the RF signal in class C amplifier operation, effectively controlling system gain to maximize power efficiency. FM+Digital and Digital-Only modes utilize fixed gain while operating class AB amplifiers for minimal signal distortions. The exciter drive level then varies to control system output power level.

Power in a digital RF mode exciter system setup is controlled by a higher power transmitter through a 4-state input with these states; mute, lower, hold, and raise. The duty cycle on this input determines system response.

Standalone transmitter and FM-only exciter setups utilize internal digital closed power control based on system forward output. Forward power approaches the active system set-point. The exciter is included in this loop when running digital power modes. FM-only closed loop is entirely contained within a PA microcontroller.

Fans are two-speed and fully turn on through active hardware logic. This logic is coupled to un-inhibit logic between the PA controller and DC power regulation circuitry.

Standard AC mains supply electrical power. An AC throw switch is included. A main power supply module converts AC to fixed DC power for use throughout the system. Power regulation systems input fixed DC and supply various lower level static and variable voltage levels to all circuitry and RF amplifiers. A fan power supply provides dedicated DC to fan(s).

There are two DB-37 connectors and a DB-25 connector to allow the STXe to interface with other equipment. This includes transmitters, remote monitoring and control, and signal generation options. With a provided cable harness, the STXe can seamlessly interface with legacy Broadcast Electronics transmitters. Using the configuration capability of the I/O pins, the STXe can be made to interface with most other manufacturers' transmitter models as well.






Figure 18 – STXe 500 System Block Diagram





## 8 Transmitter Control Center

Initial system setup after installation requires interfacing with the LCD display and buttons on the front of the main assembly. Once initial setup is complete, almost all configurations accessible on this control center can be modified remotely via Ethernet interfaces.




Figure 19 – Transmitter Control Center

### 8.1 Contrast Control

A potentiometer tuning tool can be used to adjust the contrast on the LCD screen if desired. Turning the potentiometer clockwise reduces contrast, and turning it counter-clockwise increases contrast.

### 8.2 **f** Left Button

The context dependent left button performs two primary functions. When navigating between screens it allows a return to the main screen from any other navigation screen. When an editing screen is entered this button moves the cursor one space to the left.

### 8.3 **g** Right Button

The context dependent right button performs two primary functions. When navigating between screens it allows a return to the first screen of the submenu tree. When an editing screen is entered this button moves the cursor one space to the right.

### 8.4 **h** Up Button

The context dependent up button performs various functions. When navigating between screens through the trunk it selects a new submenu tree. After entering a submenu screen it either selects different branches or cycles through options. When an editing screen is entered this button modifies the object located at the cursor.

## 8.5 **i** Down Button

The context dependent down button performs various functions. When navigating between screens through the trunk it selects a new submenu tree (in the opposite direction as the up button). After entering a submenu screen it either selects different branches or cycles through options. When an editing screen is entered this button modifies the object located at the cursor.

## 8.6 **8** Return Button

The context dependent down button performs two primary functions. When navigating between screens through the trunk it enters the next level in the menu. This can lead to submenu screens, options selection, or field editing. Once an editing function has been made this saves the field and returns to the first screen in the submenu tree.








Figure 20 – Transmitter Control Center Menus Sheet 1








Figure 21 – Transmitter Control Center Menus Sheet 2





## 9 Basic Web Page

The STXe system comes standard with a built in small-capacity HTTP web server. To load the web page, simply direct a standard web browser on a local- or network-connected PC to the IP address assigned to the controller – static IP set during system installation, or dynamic host control regulated by the network.

To check the current web interfaces version, simply point a web browser to [IP Address]/rev.html




Figure 22 – Basic Web Interface Main Page

The basic settings and monitoring fields in the system are shown above in Figure 22 – Basic Web Interface. To cycle through the active user selection click the “**Current User**” link in the upper left. To access PA monitoring information or the event log click on “PA STATUS” or “EVENT LOG” links respectively. These can be seen in Figure 24 and Figure 25.

Posting any settings to the exciter requires an appropriate login. The graphic button objects are disabled for user types that do not have permission to modify exciter settings. Once an adequate user selection is made, the buttons can be clicked to display input options. When the change is attempted a dialog box will pop up, shown in Figure 23. Simply enter the active user type (exactly as displayed in the upper left of the page) and the correct 8-digit numerical password that goes with it to save the setting.

**NOTE:** The transmitter is shipped with both of the passwords set to a default of “00000000”.

However, as a security measure, the password “00000000” is not accepted as valid by the transmitter. The customer must change the password to something other than “00000000” before remote operation is allowed. The password can only be changed at the front panel.

Refer to Section 4.3 regarding setting the passwords.

Password entry times out after 10 seconds. If the password entry session times out, simply try again in a new session. Valid login is remembered for the active session only. If the user changes to a different sub-page in the Standard HTTP interface, the password is lost and it will need to be re-entered.

Current User: chief

## STX GEN 2 STATUS PAGE

|       |         |    |            |      |          |      |
|-------|---------|----|------------|------|----------|------|
| AUDIO | EXCITER | PA | PA PWR SUP | VSWR | FAILSAFE | MUTE |
|-------|---------|----|------------|------|----------|------|

**TRANSMITTER FAULTS**

|             |             |
|-------------|-------------|
| 0           | 0           |
| FWD PWR - W | RFL PWR - W |

Authentication Required

App/10.24.174 is requesting your username and password! The site says: "STX chief"

User Name:

Password:

OK Cancel

|         |
|---------|
| 7-07-17 |
| Date    |

|                 |
|-----------------|
| 98.10           |
| Frequency - MHz |

**TRANSMITTER DATA - 1 of 3**

|     |      |   |   |
|-----|------|---|---|
| AES | NONE | 0 | 0 |
|-----|------|---|---|

Figure 23 – Basic Web Interface Authentication

## PA STATUS PAGE

|             |             |           |               |      |             |    |      |  |          |      |
|-------------|-------------|-----------|---------------|------|-------------|----|------|--|----------|------|
| 60          | 2           | 65        | 351           |      | 4.51        |    |      |  | 31.9     | 22.7 |
| FWD PWR - W | RFL PWR - W | RF to ant | DRV I - mVrms |      | PA Temp - C |    |      |  | Temp - C | Flt  |
| DRIVE       | VSWR        | FINAL I   | FOLD BK       | MUTE | PA TEMP     | PS | COMM |  |          |      |

**PA1 - DATA**

MAIN STATUS

Figure 24 – Basic Web Interface PA Page

## EVENT LOG

MAIN STATUS: STXe 500 Tx Serial # 1111111-500

| #  | TIMESTAMP           | EVENT | SOURCE     | TYPE  | PARAM | DESCRIPTION                    |
|----|---------------------|-------|------------|-------|-------|--------------------------------|
| 10 | 2017-07-05 15:15:52 | 6001  | Controller | Event | 0     | Transmitter On                 |
| 9  | 2017-07-05 15:15:32 | 6002  | Controller | Event | 0     | Transmitter Off                |
| 8  | 2017-07-05 13:29:00 | 6004  | Controller | Event | 1     | Audio Select Change Analog L+R |
| 7  | 2017-07-05 13:15:22 | 6001  | Controller | Event | 0     | Transmitter On                 |
| 6  | 2017-07-05 09:43:26 | 6015  | Controller | Event | 0     | Transmitter Unmuted            |
| 5  | 2017-07-05 09:43:26 | 6017  | Controller | Event | 0     | System Powerup                 |
| 4  | 2017-06-27 14:44:59 | 6002  | Controller | Event | 0     | Transmitter Off                |
| 3  | 2017-06-27 14:44:49 | 6001  | Controller | Event | 0     | Transmitter On                 |
| 2  | 2017-06-27 13:57:07 | 6015  | Controller | Event | 0     | Transmitter Unmuted            |
| 1  | 2017-06-27 13:57:07 | 6017  | Controller | Event | 0     | System Powerup                 |

Figure 25 – Basic Web Interface Events Page



## 9.1 RDS and FSK Setup

To enter static RDS information or FSK ID data such as Translator Identification, use the “Internal RDS Setup” link from the Basic Web page, Figure 26, to access the RDS Setup Page, Figure 27.




Figure 26 – Internal RDS Setup Link




Figure 27 – RDS Setup Page

## 9.2 Audio Delay Setup

This is an adjustable audio delay to help set up a single-frequency network, or a repeater station by getting the delays of the system in sync.

The audio delay sets the amount of time from when the analog/AES/AES-Comp signal arrives at the rear panel until it affects the modulation of the RF signal. The audio delay is settable with an integer number, (steps) from 0 to 8128, where each step is on the order of 5.3 micro-seconds. This correlates to a delay range from 0 to 43.7 milliseconds.

Current User: chief

### STX GEN 2 STATUS PAGE

|       |         |    |            |      |          |      |
|-------|---------|----|------------|------|----------|------|
| AUDIO | EXCITER | PA | PA PWR SUP | VSWR | FAILSAFE | MUTE |
|-------|---------|----|------------|------|----------|------|

TRANSMITTER FAULTS

|                    |                              |                        |              |                      |                   |                  |                    |
|--------------------|------------------------------|------------------------|--------------|----------------------|-------------------|------------------|--------------------|
| 500<br>FWD PWR - W | 5<br>RFL PWR - W<br>100% Max | 500<br>T. Setpoint - W | ON<br>ON/OFF | RESET<br>Fault Reset | DISABLE<br>Preset | 14:45:49<br>Time | 2017-07-17<br>Date |
|--------------------|------------------------------|------------------------|--------------|----------------------|-------------------|------------------|--------------------|

TRANSMITTER READINGS/INDICATIONS

|                          |               |                        |                      |                       |                 |                     |
|--------------------------|---------------|------------------------|----------------------|-----------------------|-----------------|---------------------|
| 98.10<br>Frequency - MHz | FM<br>PA Mode | 75 µSEC<br>Preemphasis | 75<br>100% Mod - kHz | STEREO<br>Stereo Mode | STEREO<br>Pilot | 10.0<br>Pilot Level |
|--------------------------|---------------|------------------------|----------------------|-----------------------|-----------------|---------------------|

TRANSMITTER DATA - 1 of 3

|                |                   |                        |                  |
|----------------|-------------------|------------------------|------------------|
| AES<br>Primary | NONE<br>Secondary | 0<br>Silence - Seconds | 0<br>Audio Delay |
|----------------|-------------------|------------------------|------------------|

TRANSMITTER DATA - 2 of 3

|              |                          |                                |                                   |                                     |                                    |                   |
|--------------|--------------------------|--------------------------------|-----------------------------------|-------------------------------------|------------------------------------|-------------------|
| AES<br>Audio | ACTIVE<br>Active/Standby | 1111111-500<br>Transmitter S/N | V3.7 S.4202<br>Version Controller | V2.3 R.3875<br>Version Exciter FPGA | V2.5 R.4024<br>Version Exciter DSP | STX-500TX<br>Type |
|--------------|--------------------------|--------------------------------|-----------------------------------|-------------------------------------|------------------------------------|-------------------|

TRANSMITTER DATA - 3 of 3

To enter a delay setting, click on the Audio Delay radio button above, to display the setting window in Figure below. Enter a number calculated from the 5.3 micro-second step amount. The example below of "20" equals a delay of 106 micro-seconds.

TRANSMITTER FAULTS

|                    |                              |                        |              |                      |                   |                  |                    |
|--------------------|------------------------------|------------------------|--------------|----------------------|-------------------|------------------|--------------------|
| 500<br>FWD PWR - W | 5<br>RFL PWR - W<br>100% Max | 500<br>T. Setpoint - W | ON<br>ON/OFF | RESET<br>Fault Reset | DISABLE<br>Preset | 15:24:40<br>Time | 2017-07-17<br>Date |
|--------------------|------------------------------|------------------------|--------------|----------------------|-------------------|------------------|--------------------|

TRANSMITTER READINGS/INDICATIONS

|                          |               |                   |                      |                       |                 |                     |
|--------------------------|---------------|-------------------|----------------------|-----------------------|-----------------|---------------------|
| 98.10<br>Frequency - MHz | FM<br>PA Mode | 75<br>Preemphasis | 75<br>100% Mod - kHz | STEREO<br>Stereo Mode | STEREO<br>Pilot | 10.0<br>Pilot Level |
|--------------------------|---------------|-------------------|----------------------|-----------------------|-----------------|---------------------|

TRANSMITTER DATA - 1 of 3

|                |                   |                        |                  |
|----------------|-------------------|------------------------|------------------|
| AES<br>Primary | NONE<br>Secondary | 0<br>Silence - Seconds | 0<br>Audio Delay |
|----------------|-------------------|------------------------|------------------|

TRANSMITTER DATA - 2 of 3

|              |                          |                                |                                   |                                     |                                    |                   |
|--------------|--------------------------|--------------------------------|-----------------------------------|-------------------------------------|------------------------------------|-------------------|
| AES<br>Audio | ACTIVE<br>Active/Standby | 1111111-500<br>Transmitter S/N | V3.7 S.4202<br>Version Controller | V2.3 R.3875<br>Version Exciter FPGA | V2.5 R.4024<br>Version Exciter DSP | STX-500TX<br>Type |
|--------------|--------------------------|--------------------------------|-----------------------------------|-------------------------------------|------------------------------------|-------------------|

TRANSMITTER DATA - 3 of 3

Audio Delay

20

OK Cancel

Figure 28 – Audio Delay Web Interface

When finished, press OK to save and exit the menu.





## 10 Enhanced Web GUI

Along with the basic web page that comes standard, STXe systems also come standard with an Enhanced Web GUI. This provides a more intuitive viewing and control experience than the Basic Web Interface while still providing all the features but in a more dynamic and user-friendly format. To access this page, click the “GRAPHICAL INTERFACE” link at the bottom of the basic web page.




Figure 29 – Link from Basic Page to GUI Main Page




Figure 30 – Enhanced Web Page

Refer to Fig 30. While navigating the screen pages, buttons that are banded in Blue are the current settings. When the PC's mouse pointer icon comes in contact with one these buttons, it will change from the user's default mouse pointer icon, (Arrow) to either the (Hand/Finger) icon or (Not-Allowed) icon, depending on the Login Profile.




Figure 31 – GUI Pointer Icons

## 10.1 Login

The default login profile is "View". This does not require a password and allows monitoring only. Basic control of system power is allowed with the "Operator" profile. Full control of all settings that can be modified through the web interface requires the "Chief" login profile.

To change the login profile, move cursor into the "view" button and a popup window will display, [click to change Logged in status] as in Figure 32 A. The previous screen being displayed will change to that in Figure 32B. Move cursor into the desired profile. In this example "Chief" is being selected.



Figure 32 – Login Profile Selection

Next, a dialog box will pop up requesting password entry. Change browser settings if this dialog box is being blocked by the browser. Enter the password and press enter or click Save and the process displayed will move to "Pending", followed by "Logged in".




Figure 33 – Password and Log In Window



Figure 34 – Profile Logged Out



## 10.2 Navigation

All of the screens in the enhanced web GUI can be accessed by clicking on the text in the navigation bar near the top of the page. The currently displayed screen pops out as shown.



Figure 35 – Navigation Bar

### 10.2.1 Main and Always-Displayed Items




Figure 36 – Main Screen

Table 7 – Main Page and Common Features

| #   | Feature                 | Description  |
|-----|-------------------------|--|
| 1.  | STX System Type         | Currently configured hardware setup type. This is determined during initial setup of the system, and might be 60W or 500W, TX (transmitter) or Exciter.                                |
| 2.  | Date and Time           | Real time clock data configured during setup.  |
| 3.  | Transmitter ON/OFF      | ON/OFF status of the final RF output (not just the control status). Transmitter setups allow RF to be turned on and off with proper login level.                                       |
| 4.  | System Block Diagram    | Overall system status. Green, amber, and red block colors correspond to front panel LED behaviors. See section 0<br><br>Front Panel Features for details.                              |
| 5.  | Power Control Set Point | Forward power value that automatic power control attempts to converge to. Note that exciter setups do not rely on this. External power control from a transmitter is utilized instead. |
| 6.  | Forward Power           | Internally measured system forward RF power output reading.  |
| 7.  | Reflected Power         | Internally measured system reflected RF power reading.   |
| 8.  | Frequency               | FM carrier frequency setting.  |
| 9.  | Modulation              | Internal frequency modulation peak hold as a percentage of peak deviation from nominal frequency.  |
| 10. | Fault/Alarm             | System faults cause this to display red, and alarms in the system cause this to display amber. Check the Logs page for details.  |

### 10.2.2 Block Diagram Figures used for Navigation

Several of the figures in the block diagrams may also provide navigation to another screen.




Figure 37 – Block Diagram for Navigation

### 10.3 Power Amplifier

The power amplifier page contains detailed status information for the internal power amplifier. Note that STXe PAs only take up one column, but the page is sized to display multiple PAs, as in 2,3, and 5kW STX LP Gen II systems as well as the STX10 HP.

Measurement meter displays scale with PA type as necessary. For example the maximum scale for 60W PAs is about 70W while the maximum scale for 500W PAs is about 550W.



Figure 38 – Power Amplifier Page

Table 8 – Power Amplifier Page Features

| #  | Feature                        | Description  |
|----|--------------------------------|--|
| 1. | Forward Power<br>FWD PWR (W)   | PA forward RF power output reading. This is also the System Forward output power in STXe systems.  |
| 2. | Reflected Power<br>RFL PWR (W) | PA reflected RF power reading. This is also the System Reflected power in single-PA STXe systems.  |
| 3. | RF Input Power<br>RF In (mW)   | PA RF drive input power reading in milliwatts.   |
| 4. | Driver Current<br>Driver (mA)  | Current in milliamperes for the driver stage RF power amplifier.   |
| 5. | Final Current<br>Final (A)     | Current in amperes for the final stage RF power amplifier.   |
| 6. | Temperature<br>Temperature (C) | Internal heat sink temperature measurement.  |
| 7. | PAV<br>PAV (V)                 | Final amplifier drain voltage. This variable voltage supply is sourced from the PA power supply.   |
| 8. | Status Balloons                | Fault and alarm indications for the PA. These will be red, yellow or green depending on the status of each item. Check the log or see Table 13 – PA Diagnostics Details in section 13.6 below for details. |



### 10.3.1 Reflected or VSWR Metering

Another feature located in the lower bar is part of the power readings. You can chose to display Reflected Power or VSWR as shown in Figure 39. The display can be toggled to either mode with proper login profile




Figure 39 - REF Power vs VSWR Feature

## 10.4 Exciter



Figure 40 – Exciter Page

Table 9 – Exciter Page Features

| #  | Feature           | Description  |
|----|-------------------|--|
| 1. | Source            | Audio input source selection. Choose one of the listed options. Composite ignores stereo generation settings.                                |
| 2. | Pre-emph          | Pre-emphasis setting for internal stereo generation.   |
| 3. | Stereo            | Mono/stereo setting for stereo generation.   |
| 4. | Pilot             | 19 kHz pilot on/off and level controls. This automatically updates with changes to the mono/stereo setting. Can be controlled independently. |
| 5. | Modulation        | Frequency deviation amount in kilohertz from nominal carrier frequency. This setting represents 100% peak frequency modulation.              |
| 6. | Secondary         | Secondary Audio input source selections. Choose one of the listed options.   |
| 7. | Transmitter Power | Automatic power control set point. Transmitter mode setups attempt to regulate total system forward output power to this value.              |
| 8. | Frequency         | Nominal FM carrier frequency.  |
| 9. | Silence Timeout   | Time allowed before loss of primary audio source switches to secondary audio source.   |

## 10.5 Input/Output



Figure 41 – Input/Output Page

The Input/Output page contains information for connections on the GPIO connector pins, shown in the left columns. These connections may be used for machine interfaces with remote station controllers/monitors or with other transmission system equipment. Refer to section 5.1 for detailed function descriptions.



## 10.6 Audio



Figure 42 – Audio Page

Table 10 – Audio Page Features

| #  | Feature                | Description  |
|----|------------------------|--|
| 1. | Source                 | Audio input source selection. Choose one of the listed options. This duplicates function in the Exciter page.  |
| 2. | Gain                   | Gain settings for hardware amplification/attenuation. AES gain is a digital scale factor.  |
| 3. | Stereo Injection Scale | Allows the stereo composite to be scaled down to balance modulation budget without changing gain calibration setup. This also scales pilot when in stereo. |
| 4. | Modulation             | Peak holds for inputs displayed as effective % of peak modulation. Composite Mod includes Unbalanced Composite, SCA1, SCA2, and RDS inputs.                |
| 5. | SCA 1, SCA 2, and RDS  | Allows on/off control and input hardware amplification/attenuation adjustment.   |

## 10.7 Logs



Figure 43 – Logs Page

Table 11 – Logs Page Features


| #   | Feature           | Description   |
|-----|-------------------|---|
| 1.  | Index             | Event index number. Initially (or after a clear) this starts at 0 and increments for every event. If the log fills, half of the current entries are deleted and numbering resumes. When 65535 entries are created, the log clears itself. |
| 2.  | Time Stamp        | Date and time of the event based on the system's internal real time clock and calendar.   |
| 3.  | Type Code         | Unique event type identification number.  |
| 4.  | Source            | Controller node from which the entry was triggered.   |
| 5.  | Classification    | Type category identification in a readable format.  |
| 6.  | Parameter         | Event-specific value for logging some changes.  |
| 7.  | Description       | Log entry details in a readable format.   |
| 8.  | Scroll            | Click the up and down arrows to scroll through the log.   |
| 9.  | Clear             | Wipes all log entries from memory permanently.<br>NOTE: Only displays when in Chief login profile.  |
| 10. | Serial Number     | Displays BE serial number and controller Ethernet MAC.  |
| 11. | Software Versions | Listing of all viewable software versions in the system.  |

## 11 SNMP

Simple Network Management Protocol is a member of the Internet Protocol standard communications suite. The STXe system comes with a built-in SNMP agent (SNMP version 2c) for handling all request types included in the protocol – GET, SET, GETNEXT, and GETBULK. The appropriate MIB for the version of SNMP agent installed on the exciter must be downloaded from the exciter itself. As with any MIB, this ASCII text file completely defines the data structure within the agent. The MIB also provides textual descriptions for every accessible object.

**SNMP IS FOR ADVANCED APPLICATION INTEGRATION. THIRD PARTY APPLICATIONS THAT UTILIZE THE SNMP INTERFACE ARE NOT SUPPORTED BY BROADCAST ELECTRONICS.**

To download the file access the web interface using a standard web browser. Right click on the “SNMP MIB File” link and click “Save link as...”. Save a local copy of the MIB file wherever desired for use in an SNMP manager application. Alternatively, click the link and navigate to the file in the browser. Right click anywhere in the viewing space and click “Save as...” Simply remove the .txt extension (leaving only the .MIB extension) and save at the desired location.



**Figure 44 – SNMP MIB Download**

An SNMP manager application must be utilized in order to access the interface. Integrating a manager into custom station automation programs provides countless possibilities. Alternatively, various third party MIB browser GUI applications are available for free download; however Broadcast Electronics does not endorse any specific application. Simply direct the manager to the Ethernet port for communication across a network.

### 11.1 Authentication

Data is accessible by using the correct community strings for the desired login level. The formula for these strings is a combination of the login type – chief, user, or operator –, a delimiting ‘+’ character, and the eight digit numerical password associated with that login type. For example, “chief+12345678” in both the read community and write community passes authentication and allows read and write to essentially every object in the MIB with the appropriate max-access type. User and Operator login levels provide more strict control over what settings can be modified and what commands can be issued in the system.

### 11.2 Objects

The SNMP interface utilizes tables wherever it makes sense to communicate data in an indexed fashion. To accommodate a scalable transmitter product design, for example, almost all PA data is structured as tables by using the PA number as the index. This works by appending “.1” to the object indicating the single PA in the system. Note that a normal “leaf” node is accessed by appending “.0” as in ...38118.2.2.2.0, the object for system forward power.

## 12 Backup Control Modes

STXe systems come equipped with two backup control methods. Emergency Control Mode is integrated standard with all systems and allows the system to continue functioning in the event of a system controller failure. The Backup System Control and Exciter feature utilizes an entire STXe system to also allow for full control interfacing with an identical standby Exciter.

### 12.1 Emergency Control Mode

In the event of a loss in communications with the system controller, all sub-systems enter emergency control mode. Behavior when in this mode depends on user specified emergency power levels. The emergency power level must be set to the desired emergency power level in order to enable the feature, which comes from the factory set at 0 W and is effectively disabled. The system will continue to function at full emergency power as long as the exciter maintains drive to the power amplifier. The power amplifier can only enter emergency power mode from a working state, so it will not unmute or initialize in the emergency power state.

### 12.2 Standby System Control and Exciter

For complete exciter redundancy an exciter switcher kit can be acquired. These kits supply all required hardware for utilization of standby STXe systems. The switcher system is then paired with a second fully functional two rack unit STXe system.

Detailed information including installation and operation of this optional configuration are contained in an application guide. A copy is included in standard kits and/or inserted in the front of the binder containing this manual if shipped as part of the same order. For electronic copies of this and any other technical documentation please visit <http://www.bdcast.com/information-center/> and follow navigation on the left side of the page – authorized login is required.



## 13 Troubleshooting

Some basic information and troubleshooting steps are included below. If problems persist after basic troubleshooting steps are taken, please contact RF Technical Services. Contact information is located on our website at [www.bdcast.com](http://www.bdcast.com) and on page iii in the front of this manual.

A fault in any part of the system indicates a complete disruption in normal operation of at least one part of the transmitter system. Once the problem has been identified, a fault reset command should always be issued through diagnostics in any user interface to attempt to recover from fault conditions. If the reset is not successful or a condition that caused a fault still remains, the fault will re-assert.

An alarm typically indicates an abnormal condition that represents a disruption that may resolve itself. Alarms in unexpected situations could indicate serious conditions. Alarms that persist or unexpectedly appear on a regular basis should not be ignored. To get a good feel for what alarms are expended under which conditions, see the alarm details in the sections that follow.

### 13.1 Event Log

The system event log can be accessed through the Basic Web Interface log page or in its raw form through the event Log tree in SNMP. An event is defined by its index starting with the first saved event at index 1, a timestamp from the system's internal real time clock, an event identification number, and the sub-system where the event triggered. Some events also have context-based parameters that are embedded in the description of the event.

### 13.2 Standby

The STXe Exciter comes with built-in functionality for a standby controller and exciter – see section 12.2 Standby System Control and Exciter. A system that is in standby is muted and not actively controlling the transmitter. This mode is not intended in a setup that has a single system controller and exciter. Standby system control and exciter setups should have no more than one unit active at a time.

If a system is locked in standby mode, this typically indicates a setup problem. Single system controller and exciter setups require a stub 949-4130 that activates the transmitter. This must be attached to the Broadcast Electronics Interface jack, see section 5.2. Dual system controller and exciter setups require a switcher system, such as the FW Exciter Switcher product series, that connects to both assemblies through this interface. The switcher must be operated to activate one controller/exciter.

### 13.3 Failsafe

An asserted failsafe input on the remote station interface is required for operation of the system. The intended usage of this input is to make a loop that passes through safety relays in all critical transmission system components. When any part of the transmission system becomes unsafe, the circuit should open and de-assert the failsafe on the transmitter. When a failsafe condition is active, check all systems that are wired into the failsafe circuit.



## 13.4 Mute

A mute generally refers to a lack of an RF source in some part of the system, and the affected part depends on the context of the notification. Mute indications can happen at various stages for different reasons, and details in system sections listed here should be considered.

Transmitter mute conditions typically refer to the FM exciter. In internal exciter setups this commonly occurs when:

- There is no power to the exciter
- The mute GPIO input pin on the remote station interface is asserted
- Unmute/Failsafe GPIO input is not asserted
- The BE Interface active input is not asserted
- VPe/XG setup presence GPIO input is active when no VPe/XG is in the system, or is not activated when it is in the system.

## 13.5 Internal Exciter Diagnostics

**Table 12 – Exciter Diagnostics Details**

| <b>Fault/Alarm</b>  | <b>Description</b>  |
|---------------------|---|
| Communication Fault | This fault occurs when communication between the System Controller and the internal Exciter is nonfunctional. |
| AFC Unlock Alarm    | Automatic frequency control system does not yet have lock.  |
| 10MHz Status        | Displays INT when exciter is on the Internal reference or EXT for when an External reference is used.         |
| Audio SCR Status    | Secondary (SCR) Audio displays PRI for primary audio or SEC for secondary audio                               |



## 13.6 Power Amplifier Diagnostics

**Table 13 – PA Diagnostics Details**

| <b>Fault/Alarm</b>             | <b>Description</b>   |
|--------------------------------|--|
| RF Power Supply Fault          | This fault activates when a power source failure is detected.  |
| Reflected Power Fault          | This fault activates when a sudden increase in reflected power is detected by hardware in the power amplifier.   |
| VSWR Fault                     | This fault activates when the measured VSWR is greater than the maximum VSWR rating of the system at any power level.  |
| Temperature Fault              | This fault activates when the measured internal heat sink temperature exceeds the safe limit.  |
| Current Fault                  | There is current monitoring on the final stage RF amplifiers. The PA shuts down when measured current on any of these solid state amplifiers exceeds the safe limit.   |
| Hardware Fault                 | This is an internal self-report of problems in PA control hardware.  |
| Communication Fault            | This fault occurs when communication between the system controller and the PA is lost.   |
| Reflected Power Foldback Alarm | During FM only operation, the PA attempts to lower its output power when reflected power approaches dangerous levels. This keeps the transmitter running at reduced power in order to prevent a reflected power fault.   |
| Temperature Foldback Alarm     | During FM only operation, the PA attempts to lower its output power when the internal heat sink temperature approaches dangerous levels. This keeps the transmitter running at reduced power in order to prevent a temperature fault.  |
| Current Foldback Alarm         | During FM only operation, the PA attempts to lower its output power when the final power transistor current approaches dangerous levels. This keeps the transmitter running at reduced power in order to prevent a current fault.  |
| Muted Input Alarm              | This alarm is asserted when in FM-only mode and the RF power from the Exciter to the PA is below the minimum threshold for safe operation. This alarm is not reported when the PA is turned off for any reason.  |
| Railed Alarm                   | During FM-only operation this indicates a condition where automatic power control has reached its highest or lowest possible control value indicating that the transmitter cannot reach the RF power set-point. The power control system automatically leaves this state if the condition is resolved. |



## 14 Maintenance

These sections detail steps to maintain or replace STXe 500 system modules and spare parts.

### 14.1 Clean the Air Filter and Check Fans

STXe 500 systems come standard with snap on washable air filters. Air filter cleaning should be a part of regular system maintenance.

While cleaning air filters, air circulation should also be verified in case fans have stopped functioning

To remove the filter from the front of the exciter, use the opening on the bottom to pry the snaps by hand.



**Figure 45 – Air Filter Removal**

Remove the filter material from the case for thorough cleaning. Use compressed air or water to remove debris.



**Figure 46 – Separated Air Filter**

Snap the air filter back on once clean.

Carefully pinch to tighten the snaps if the case became loose enough to rattle.



## 14.2 Remove the Top Cover

To perform remaining module replacement actions in the maintenance section, the top cover must be removed. Full precautions should be taken against electrostatic discharge. Any such shocks may cause permanent damage to any electronic components, especially printed circuit boards.



**ENSURE AC POWER INPUT IS COMPLETELY DISCONNECTED BEFORE ACCESSING ANY INTERNAL MODULES**

Use a Phillips screwdriver to unscrew all 9 top cover screws and lift the cover.




Figure 47 – Top Cover

### 14.3 Main Power Supply



**Figure 48 – Main Power Supply**

- ☐ 540-0048 Power Supply Board Assembly, 48VDC 1kW
- ☐ Phillips Screwdriver

1. Use a Phillips screwdriver to disconnect the red and black DC wiring. Pop the polycarbonate cover off the AC screws and use a Phillips screwdriver to disconnect the three wires.



**Figure 49 – Main PS Wires**

2. Use a Phillips screwdriver to remove the two screws securing the power supply to the main chassis.



**Figure 50 – Main PS Chassis Screws**

3. Loosen the internal thumb screws by hand.



**Figure 51 – Main PS Internal Thumb Screws**

4. Tilt up, slide, and lift the power supply out of the chassis as shown.



**Figure 52 – Main PS Extraction**

5. Remove the three screws from the main power supply chassis section.



**Figure 53 – Main PS Chassis Section**

Repeat the previous steps in reverse with the replacement power supply module.

## 14.4 AC Switch


The AC switch should only be replaced if it is known to have failed. Plastic retaining snaps must be deformed or destroyed to remove the switch from the chassis.



**Figure 54 – AC Switch**

- ☐ 349-0020 1 20A double pull single throw rocker switch
- ☐ Phillips screwdriver
- ☐ Side cutters
- ☐ 3/4" wrench
- ☐ 5/8" wrench

1. Use a Phillips screwdriver to remove the five screws that secure the back panel to the main chassis: one on either side and three on the bottom.



**Figure 55 – Back Panel Screws**

2. Use a 3/4" wrench to remove the N-Type connector nut and lock washer.



**Figure 56 – N-Type Connector Nut**

3. Use a 5/8" wrench to remove the sample output BNC nut and lock washer.



**Figure 57 – BNC Connector Nut**

4. Remove the CPE screw and unsnap the corners.



**Figure 58 – CPE Screws and Snaps**



5. Carefully lift and rotate the assembly to gain easy access to the AC switch.



**Figure 59 – Displaced Back Panel Assembly**

6. Use side cutters to cut the AC switch's housing tabs. The switch should then slip through the chassis as shown.



**Figure 60 – AC Switch Tabs**

7. Exchange wires from the old switch to the replacement switch one at a time to ensure that wires are placed in the correct configuration.



**Figure 61 – AC Switch Wires**

8. Insert the switch back into the chassis and repeat the initial steps in reverse to replace the back panel and controller/exciter board.

## 14.5 AC Input and EMI Filter



**Figure 62 – AC Input Replacement Parts**

- ☐ 339-0006 1 10A 50/60 Hz 250V AC input filter
- ☐ 402-0015 1 Cable tie
- ☐ 611-1501 4" 1-1/2" diameter heat shrink wrap
- ☐ Phillips screwdriver
- ☐ Side cutters
- ☐ Heat gun

1. Use side cutters to cut the cable tie.



**Figure 63 – AC Cable Tie**

2. Cut the shrink wrap.




**Figure 64 – Cut Shrink Wrap**

3. Carefully pull the three wires off the exposed internal studs.




**Figure 65 – AC Studs**

4. Use a Phillips screwdriver to remove the two screws that secure the input shell to the chassis.



**Figure 66 – AC Input Screws**


5. Slide the AC assembly out of the chassis. Place its replacement in the same spot, and secure it with the Phillips screws.



**Figure 67 – AC Input Assembly Removal**



6. Feed the wires through the shrink wrap. Hold the wrap back and secure the wires on the internal studs. Ensure proper wire placement per wire colors indicated in the figure.



**Figure 68 – Internal AC Connections**

7. Slide the shrink wrap all the way up and over the AC input assembly. Apply heat with a heat gun.



**Figure 69 – Shrink Wrap**

8. While the shrink wrap is still malleable, secure it with the cable tie.

## 14.6 Fan Power Supply



Figure 70 – Fan Power Supply

- |   |   |  |
|---|---|--|
| <input type="checkbox"/> 540-5024             | 1 | Power Supply Board Assembly, 24VDC 50W |
| <input type="checkbox"/> Phillips Screwdriver |   |  |



**POWER SUPPLY PARTS MAY HOLD THEIR CHARGE FOR MINUTES AFTER AC POWER IS DISCONNECTED. SHOCKS AND BURNS MAY RESULT IF JACKS OR PART LEADS ARE TOUCHED, ESPECIALLY ON THE BOTTOM OF MODULES!**

1. Disengage latches on wire connectors and unplug them.




Figure 71 – Fan Power Supply Connectors

2. Use a Phillips screwdriver to remove the four screws that secure the power supply.



Figure 72 – Fan PS Screws

3. Carefully lift the power supply out of the chassis.



**Figure 73 – Fan PS Extraction**

Repeat the previous steps in reverse with the replacement power supply module. The cable latches should engage when the cables are fully plugged. Ensure solid latching on all cables.

## 14.7 Fan



**Figure 74 – Fan**


- ☐ 380-9008-001      1 or 2   Fan with Connector, 24V 80 mm X 38 mm
- ☐ Phillips Screwdriver

1. Slide the fan assembly straight up and out of the chassis by lifting the polycarbonate.




**Figure 75 – Fan Assembly Extraction**

2. Pinch connector latches and then pull apart to disconnect wires.




**Figure 76 – Fan Connectors**

3. Note the front/back and wired corner orientations relative to the polycarbonate cutout.



**Figure 77 – Fan Orientations**

4. Use a Phillips screwdriver to remove the four (or eight) screws and self-locking nuts that secure the fan(s) to the case.



**Figure 78 – Fan Screws**

Repeat the previous steps in reverse with the replacement fan(s). Ensure fan direction and orientation in the case is proper to direct airflow and minimize strain on cables.

## 14.8 Fuse – DC Regulator



Figure 79 – 20A DC Fuse

- ☐ Digital multi-meter with Ohm metering
- ☐ 330-0062 1 20A Fuse
- ☐ Phillips Screwdriver
- ☐ Tweezers
- ☐ Soldering Iron(s)
- ☐ Solder

1. Use a Phillips screwdriver to remove the two screws securing the power supply to the main chassis.



Figure 80 – Main PS Chassis Screws

2. Loosen the internal thumb screws by hand.



Figure 81 – Main PS Internal Thumb Screws



3. Tilt up, slide, and lift the power supply out of the chassis. Carefully set the power supply unit aside as shown.



**Figure 82 – DC Regulator Fuse Access**

4. Locate the fuse and verify failure with an Ohm meter. A normal fuse will be a short circuit near 0 Ohm, and blown fuses will be an open circuit with a very high Ohm reading.



**Figure 83 – DC Regulator Fuse Location**

5. Use soldering irons to carefully remove the fuse from the circuit board.
6. Use tweezers to hold the new fuse in place on the pads. Use a soldering iron to apply heat and add solder as needed.


## 14.9 DC Regulator



**Figure 84 – DC Regulator Board Assembly**


- ☐ 919-4212                      1              DC Regulator Board Assembly
- ☐ Phillips Screwdriver

1. Disengage latches on the blue connectors and pull them. Pull the three white cable connectors. Set the cable ends aside.



**Figure 85 – DC Regulator Cables**

2. Use a Phillips screwdriver to remove the three screws.



**Figure 86 – DC Regulator Screws**

3. Pop the board assembly off the four corner snaps.





**Figure 87 – DC Regulator Snaps**

4. Lift the board out of the chassis.



**Figure 88 – DC Regulator Extraction**

Repeat the previous steps in reverse with the replacement DC regulator board assembly.

## 14.10 Fuse – Low Voltage



**Figure 89 – 1.5A Low Voltage Fuse**

- ☐ Digital multi-meter with Ohm metering
- ☐ 330-0006                      1                      1.5A Fuse
- ☐ Tweezers
- ☐ Soldering Iron(s)
- ☐ Solder

1. Locate the fuse and verify failure with an Ohm meter. A normal fuse will be a short circuit near 0 Ohm, and blown fuses will be an open circuit with a very high Ohm reading.



**Figure 90 – Low Voltage Fuse Location**

2. Use soldering irons to carefully remove the fuse from the circuit board.
3. Use tweezers to hold the new fuse in place on the pads. Use a soldering iron to apply heat and add solder as needed.

### 14.11 Fuse – Driver Power Amplifier



**Figure 91 – 1.5A Driver Amplifier Fuse**

- ☐ Digital multi-meter with Ohm metering
- ☐ 330-0006 1 1.5A Fuse
- ☐ Tweezers
- ☐ Soldering Iron(s)
- ☐ Solder


4. Locate the fuse and verify failure with an Ohm meter. A normal fuse will be a short circuit near 0 Ohm, and blown fuses will be an open circuit with a very high Ohm reading.



**Figure 92 – Driver Fuse Location**

5. Use soldering irons to carefully remove the fuse from the circuit board.
6. Use tweezers to hold the new fuse in place on the pads. Use a soldering iron to apply heat and add solder as needed.

## 14.12 Fuse – Final Power Amplifier



**Figure 93 – 25A Final Amplifier Fuse**

- ☐ Digital multi-meter with Ohm metering
- ☐ Tweezers
- ☐ 330-0063                      1                      25A Fuse
- ☐ Soldering Iron(s)
- ☐ Solder

1. Locate the fuse and verify failure with an Ohm meter. A normal fuse will be a short circuit near 0 Ohm, and blown fuses will be an open circuit with a very high Ohm reading.



**Figure 94 – Final Amplifier Fuse Location**

2. Use soldering irons to carefully remove the fuse from the circuit board.
3. Use tweezers to hold the new fuse in place on the pads. Use a soldering iron to apply heat and add solder as needed.

### 14.13 Drive Power Amplifier Part

RF power transistors should only be replaced if they are known to have failed. Bending leads to separate from boards during the removal process will cause damage. Fuses and other components in surrounding circuitry may also be damaged depending on the failure mode.

This is a difficult process that should only be attempted by skilled technicians.



**Figure 95 – Driver Stage Power Amplifier**

- ☐ 210-2918 RF Power Amplifier
- ☐ 700-0028-004 Thermal Compound
- ☐ 6 lb-in (0.6-0.75 Nm) Torque Phillips Screwdriver
- ☐ Pliers/tweezers
- ☐ Solder
- ☐ Soldering Irons
- ☐ Solder Wick

1. Identify the amplifier device to be replaced.



**Figure 96 – Driver Amp Location**

2. Use a soldering iron to remove the capacitor and resistor




**Figure 97 – Driver RC Parts**

3. Use a Phillips screwdriver to remove the mounting screws.
4. Use a soldering iron and pliers to bend up and separate leads from the circuit board. Remove the part when finished.
5. Solder wick residual solder to remove it from the circuit board to prevent lead strain.
6. Apply a thin film of thermal compound to the bottom of the replacement amplifier part where the base of the part contacts the heat sink.



**Figure 98 – Driver with Thermal Compound Applied**

7. Place the part and look at the notch to ensure the proper orientation. Use the Phillips torque wrench to tighten the screws with about 6 in-lb of Torque.



**Figure 99 – Driver Placement**

8. Use pliers and a soldering iron to gently bend the end of a lead to the board one at a time and apply solder. Minimize strain on the leads. Do this for all four leads.
9. Place the leaded resistor and the capacitor in series across the part just as before.

Performance of the module after the amplifier part replacement process has been completed may depend on part to part variations of the amplifier parts and surrounding circuitry. If there is degradation in performance please contact BE technical services to arrange to ship the module/system for diagnosis, repair, and re-tuning.



## 14.14 Final Power Amplifier Part

This is a difficult process that should only be attempted by skilled technicians. The FPA Palate that the part is mounted on can be removed for ease of access. Follow directions in section 14.15 if desired.

- ☐ 210-0188 Final Amplifier Part
- ☐ 700-0028-004 Thermal Compound
- ☐ 6 lb-in (0.6-0.75 Nm) Torque 3/32" Allen (hex key) wrench
- ☐ Pliers/tweezers
- ☐ Solder
- ☐ Soldering Irons
- ☐ Solder Wick

1. Use soldering irons to remove the input inductor.



Figure 100 – Final PA Input Inductor


2. Use soldering irons to disconnect the white coaxial cable ends.



Figure 101 – Final PA Output Coaxial Cables




3. Use 3/32" Allen wrench to remove the two mounting screws and all washers.



**Figure 102 – Final PA Mounting Screws and Washers**

4. Use soldering irons on each of the four leads to disconnect the part from the circuit board.
5. Lift the part up and out of the Palate.
6. Use solder wick with remove residual solder where the new part leads will go.
7. Apply a thin film of thermal compound to the entire bottom of the new part.
8. Place the part in the mounting location (note the notch location) and secure the screws and washers with a 6 lb-in Torque 3/32" Allen wrench.
9. Apply solder to all four leads.
10. Use soldering irons and solder as necessary to place the output coaxial cables. Refer to Figure 101.
11. Place the input inductor. Refer to Figure 100.
12. Bend each coaxial cable such that they are both 0.55"  $\pm$  0.030" from the highest point to the circuit board surface.



**Figure 103 – Final PA Coaxial Cable Heights**

Performance of the module after the amplifier part replacement process has been completed may depend on part to part variations of the amplifier parts and surrounding circuitry. If there is degradation in performance please contact BE technical services to arrange to ship the system for diagnosis, repair, and re-tuning.



## 14.15 Final Power Amplifier Palate



**Figure 104 – Power Amplifier Palate**

- ☐ 959-4500 500W PA Palate
- ☐ 700-0028-004 Thermal Compound
- ☐ Phillips screwdriver
- ☐ Pliers/tweezers
- ☐ Solder
- ☐ Two Large Soldering Irons

1. User large soldering irons to disconnect DC power input.



**Figure 105 – Palate DC Input**

2. User large soldering irons, one on the outer conductor and one on the inner conductor, to lift the RF output coaxial cable.



**Figure 106 – Final RF Output**

3. Do not remove the screws that secure the board to the palate. Use a Phillips screwdriver to remove the 7 palate mounting screws and lock washer. Bend the white coaxial cable up or down as needed.



**Figure 107 – Palate Screws**

4. Lift the palate straight up to disengage the connector.
5. Spread a thin film of thermal compound on the bottom of the replacement palate.



**Figure 108 – Palate with Thermal Compound**

6. Repeat steps 1 through 4 in reverse to install the new final PA palate.
7. Once mounted successfully, bend each white coaxial cable up such that they are both  $0.55'' \pm 0.030''$  from the highest point to the circuit board surface. Bend the output coax such that it is  $0.80'' \pm 0.030''$  from the highest point to the circuit board surface.



**Figure 109 – Palate Coaxial Cable Heights**

## 14.16 Power Amplifier and Low Pass Filter Assembly

This section details a difficult process that should only be attempted by skilled technicians.



Figure 110 – Power Amplifier Assembly




Figure 111 – Low Pass Filter Circuit Board Assembly

- |  |   |                                |
|--|---|--------------------------------|
| <input type="checkbox"/> 959-4500-100                          | 1 | 500W PA Assembly               |
| And/Or   |   |                                |
| <input type="checkbox"/> 919-4060-100                          | 1 | Low Pass Filter Board Assembly |
| <br>   |   |                                |
| <input type="checkbox"/> Phillips Screwdriver                  |   |                                |
| <input type="checkbox"/> Extra-Long/Short Phillips Screwdriver |   |                                |
| <input type="checkbox"/> 3/4" wrench                           |   |                                |
| <input type="checkbox"/> 5/8" wrench                           |   |                                |
| <input type="checkbox"/> 5/16" Nut Driver                      |   |                                |



1. Use a Phillips screwdriver to remove the two circled screws on the bottom of the unit.



**Figure 112 – Bottom PA Screws**

2. Use a Phillips screwdriver to remove the screw on the side.



**Figure 113 – Side PA Screw**

3. Insert an extra-long Phillips screwdriver through the hole in the back of the chassis and unscrew the PA screw. An extra-short Phillips screwdriver that can fit inside the cavity is also valid.



**Figure 114 – Front PA Screw**

4. Use a 3/4" wrench to remove the N-Type connector nut and lock washer.




**Figure 115 – RF OUT Nut**

5. Use a 5/8" wrench to remove the sample output BNC nut and lock washer.



**Figure 116 – RF Sample Nut**


6. Disconnect all cables from the PA assembly.



**Figure 117 – PA Assembly Cables**


7. Slide the N-Type and BNC connectors out of their D-holes and displace the PA assembly.

8. Remove the CPE board screw and gently lift the board off the corner snap.



**Figure 118 – CPE Screw and Snap**

9. Gently flex the board to move the low pass filter ribbon cable out from beneath the board assembly.



**Figure 119 – Low Pass Filter Ribbon**

10. Lift the PA assembly straight up out of the chassis and set it next to the system.
11. Use a Phillips screwdriver to remove the five screws that secure the low pass filter board assembly.



**Figure 120 – Low Pass Filter Screws**



12. Disconnect the ribbon cable from the board assembly.




**Figure 121 – Low Pass Filter Ribbon**

13. Gently flex the board forward and slide the ribbon cable back through the slot in the chassis.



**Figure 122 – Low Pass Filter Ribbon Extraction**

14. Prop the PA assembly up so that the low pass filter board assembly is almost horizontal (this keeps solder from dripping out of control). Use large soldering irons to disconnect the coaxial cable, one on the center conductor and one on the outer conductor.



**Figure 123 – Low Pass Filter RF Input**

15. Set the PA assembly back down and use large soldering irons in the same way to disconnect the final PA palate output as shown.



**Figure 124 – Final PA Palate RF Output**

16. Use a 5/16" nut driver to remove the self-locking nut that secures the low pass filter.




**Figure 125 – Low Pass Filter Nut**

17. Slide the low pass filter out of the chassis section. If replacing the low pass filter only, the next three steps can be skipped.
18. Use a Phillips screwdriver to remove the three screws that secure the chassis section to the PA heat sink.



**Figure 126 – Low Pass Filter Chassis Section Screws**

19. Use a 5/16" nut driver to remove the self-locking nut that secures low pass filter chassis section.



**Figure 127 – Low Pass Filter Chassis Nut**

20. Use a Phillips screwdriver to remove the screw that holds the end of the low pass filter chassis section.



**Figure 128 – Chassis Section Screw**

Repeat the previous steps in reverse with the replacement PA module, the replacement low pass filter board assembly, or both.

Performance of the system after the amplifier or low pass filter replacement process has been completed may depend on part to part variations of the amplifier and surrounding circuitry. If there is degradation in performance please contact BE technical services to arrange to ship the system for diagnosis, repair, and re-tuning.


## 14.17 Front Panel Display



**Figure 129 – Front Display Board Assembly**

- ☐ 919-4207 1 STX CPE Display Board Assembly
- ☐ Short Phillips Screwdriver

1. Use a short Phillips screwdriver to remove the two screws securing the board assembly.



**Figure 130 – Front Display Screw**

2. Disengage the latch on the cable harness and disconnect it from the display board.



**Figure 131 – Front Display Plug**

3. Reach in the left of the board and unsnap the two corners.



**Figure 132 – Front Display Left Snaps**

4. Angle the board out and unsnap the other two corners.



**Figure 133 – Front Display Right Snaps**

Repeat the previous steps in reverse with the replacement front panel display board assembly.



## 14.18 Extended I/O



Figure 134 – Extended I/O Board

□ 3/16" Nut Driver

1. Unplug the cable harness by pinching the latches and lifting.




Figure 135 – Extended I/O Cable

2. Use a 3/16" nut driver to remove the jack screws and lock washers.



Figure 136 – Extended I/O Jack Screws

Repeat the previous steps in reverse with the replacement extended I/O board assembly.

## 14.19 Controller Exciter



**Figure 137 – Controller Exciter Board**


- ☐ 919-4200-100      1      STX Controller Exciter Board Assembly
- ☐ Phillips Screwdriver
- ☐ 3/16" Nut Driver
- ☐ 9/16" wrench (or machine-thinned 9/16" deep-well nut driver)

1. Follow the steps in section 0 to remove the extended I/O board.
2. Use a 3/16" nut driver to unscrew the four D-Subminiature jackscrews and lock washers that secure the GPIO and BE INTERFACE jacks.



**Figure 138 – CPE D-Subminiature Jackscrews**

3. Use a Phillips screwdriver to remove the six screws that secure the XLR jacks.




**Figure 139 – CPE XLR Screws**

4. Use a 9/16" wrench to loosen the six BNC nuts. Space is tightly constrained, and once the nuts are loose they can be removed by hand.



**Figure 140 – CPE BNC Nuts**

5. Disconnect all cables from the Controller Exciter board. Unseat the cables from the notch in the chassis wall and set them out of the way.



**Figure 141 – CPE Cables**

6. Pop the polycarbonate cover and use a Phillips screwdriver to loosen and slide the AC wiring off of the main power supply. This allows clearance during board extraction.



**Figure 142 – Main PS AC Wiring**



7. Use a Phillips screwdriver to remove the screw securing the board.



**Figure 143 – CPE Screw**

8. Gently lift the board next to each of the two snaps and free the board.



**Figure 144 – CPE Snaps**

9. Slide the coaxial cable forward in the harness to allow required clearance.



**Figure 145 – Coaxial Cable Displacement**

10. Angle the back of the board up and slide the connectors back until the XLR latches contact the chassis as shown. Gently tuck the latches under to free the board.



**Figure 146 – Board Extraction**

Repeat the previous steps in reverse with a replacement Controller Exciter board assembly.