

Avatar FM Direct Sampling Test Set – Quick Start Guide Hardware and OS minimum requirements

- Windows 7 or Windows 10
- RAM: 4 GB
- CPU 2.5 GHz 4 Core
- HD: 10 GB free
- Screen 1600x900

Software installation

1. Download the Avatar setup files here: Link

You will need Local Admin permissions to your PC in order to successfully complete this installation.

2. Connect the Signal Predator to an USB port of your PC checking on the back panel that the power switch is on. If the computer asks to search and install drivers, confirm it.



3.Launch the Avatar Setup software. Click Next.

ANNORS 1.1530 Setup	Welcome to AVATAR 1.13.0 Setup				
	Setup will guide you through the installation of AVATAR 1.13.0. It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer. Click Next to continue.				
	Next > Cancel				

- 4. Accept the default installation location. Click Install.
- 5. The installation routine will run through a number of screens, including a SQL Server setup.

6.If you are connected to Internet the software will search for update of the SQL software. If you are not connected to the internet, the installation will continue with the current version. the software 2012 Setup - □ ×

all Setup Files						
	Downloading the Setup files: 0 MB of 26 MB downloaded (0 %)					
	Task	Status				
	Scan for product updates	Completed				
	Download Setup files	In Progress				
	Extract Setup files	Not started	Not started			
	Install Setup files	Not started				

7. Click the Close Button when advised installation is complete.

etup was completed successfully.	
xtract: SQLEXPR_x86_ENU.exe 100%	
Execute: InfDefaultInstall "C: \Program Files (x86)\Elenos\Elenos\Elenos Telemetria\DRIVER\	^
Installazione driver HW: 0	
Output rober: C: program Files (x86) perios perios relenenta Dalata file: C: Drogram Files (x86)/Elenos Talamatria/SOI (SOI EVER. x64, EMI)	
Delete file: C. Program Files (v86)/Elence Telemetria DQL DQLEXPR_X01_DIG Delete file: C-IDvorram Eles (v86)/Elence Telemetria ISOI ISOI EVD0 v86 ENI I	
Delete file: C: Program File: (x86)/Elenne/Elenne Telemetria/DOTNETWD0462-X8315	
Remove folder: C-IProgram Files (v86)/Elenos/Elenos Telemetria/DOTNET1	
Remove folder: C:\Program Files (x86)\Elenos\Elenos Telemetria\SOL1	
Created uninstaller: C: Program Files (x86)/Elenos/Elenos Telemetria/Uninstall.exe	1
Completed	
	-



8. The software will now install the drivers for the hardware.

E Windows Security		×
Would you like to install this device	software?	
Name: ELAD srl Italy Publisher: ELAD Srl		
Always trust software from "ELAD Srl".	Install	Don't Install
You should only install driver software from decide which device software is safe to ins	n publishers y tall?	ou trust. <u>How can l</u>

Do not disconnect the hardware even if requested. Click OK



At this stage you will have an icon on the desktop like this:



9. Launch the Software from the desktop icon or from the installation directory (C:\Program Files (x86)\Elenos \Elenos \Elenos Telemetria \schedule.exe).

10. Windows may display a Firewall Security alert. Click "Allow access".

V app			
Vindows Defend etworks.	er Firewall has bl	ocked some features of Avatar on all public and private	
_	Name:	Avatar	
_	Publisher:	Elenos	
	Path:	C:\program files (x86)\elenos\elenos telemetria \schedule.exe	
Now Avatar to c	ommunicate on t	hese networks:	
Private ne	tworks, such as r	ny home or work network	
Public net: because th	vorks, such as th hese networks of	ose in airports and coffee shops (not recommended ten have little or no security)	
		the state of the s	



Page 3 of 12

11. When presented with the "Manutenzione" page, leave all boxes blank and click on "Salva". Click the wrench icon in the instrument menu bar at the bottom of the screen.



12. The software will load and display an entry code page. Leave all digits at "0" and click "GO"



13. Connect an antenna to the Avatar and you are ready to receive a signal.





14. The interface is very intuitive: simply select your desired frequency from the interface and click the triangular "play" button.

15. You can enter saved presets using the wrench icon.

16. Note that frequencies are entered in Hz (not MHz). Click "SALVA" button to save. Also note that the actual preset button names are offset: e.g., Preset M1 uses button M0. This will be corrected in a future SW release.

17. In the U.S.A, you should set De Emphasis to 75 µs. (Wrench icon > Graph tab

IP	MEM	GRAPH	ALARM				
De	e Empha		NONE	🕒 50 µз	O 75 µs		
\sim	Abilita S	ifondo Gi	rafico				
Gr	afico		255 255 255	 Max 	Hold	128 0 0	1



Navigating Avatar

Main Screen Overview:



You can enlarge each of the instrumentation screens by double-clicking on them. Instrumentation screens may be rearranged by dragging and dropping them into place. Close any instrumentation screen by clicking the "X" button in the upper-right corner.



Instrumentation Screen Details:

RF Spectrum

The RF input spectrum in dBm , +/- 300 kHz around the center frequency is shown with:

- instantaneous value (white)
- mean value (pink)
- maximum hold value (red)
- minimum hold value (blue)



RF SPECTRUM

(Max - Min - Mean -Real Time)



Spectrogram

Sequentially accumulating slices of the instantaneous RF input spectrum create a waterfall history called Spectrogram, providing information about spectrum occupancy. The amplitude in dBm corresponds with the color bar on the left.



SPECTROGRAM

Multiplex Spectrum

This screen shows the spectrum in dBm of the FM demodulated signal from 0 to 100 kHz (Composite Multiplex).

- 0-15 kHz : L+R
- 19KHz : Stereo pilot tone
- 23-53 kHz : L-R
- Around 57 kHz : RDS/RBDS



- White: Instantaneous value
- Pink: Mean value
- Red: Maximum hold value
- Blue: Minimum hold value

Page 8 of 12



Audio Spectrum

This screen shows the 0-15 kHz spectrum of the Audio signal, decoded from the Multiplex. The seamless measurement of S/N without interruption or insertion of test tones is an exclusive and patented feature of the Avatar FM Direct Sampling Test Kit. It provides a continuous quality check from within the listening area.



S/N is displayed on the right top of the screen, computed automatically at 1 kHz. Values at different frequencies can be computed from the difference of the red trace (maximum hold) and the blue trace (minimum hold). The white trace is the instantaneous value.

To select L,R, L+R, or L-R, simply double-click the screen. Measurement will restart with new settings.



Deviation





The two bar graphs display the maximum peaks for easier evaluation. Double-click the screen to configure unique measurements.

Deviation History

This screen shows the maximum peak FM Deviation (positive or negative) reached on a longer time-scale.





Deviation Histogram

This screen displays the statistical distribution of the FM peak deviation



(This sample has been highly compressed to be loud)

- M: mean deviation (kHz)
- SD: standard deviation (kHz)
- V: variance (kHz)

Modulation Power

This screen shows the modulation power as defined in the ITU-R BS.641 & ITU-R BS.412-9, during the time. Modulation power and "loudness" are corelated.



Stereo Monitor

This screen displays the L&R channels over time as a dual trace oscilloscope with the scale in percentage.



Additional traces can be configured by double-clicking on the screen.

Stereo Quality

This screen plots the L&R signals on the X &Y axis.



Differences between the L&R signals are represented by distances between the points This sample displays a good quality Stereo image, with its clustered data. For Mono signals (L always equal to R) you will always see a line at 45°. The red line is the maximum hold trace.



